


How to Uninstall Blinds

Press the lever at the base of the bracket and pull the blind toward you to uninstall.



One Year Warranty

This warranty is provided . This warranty applies only our products that meet the following conditions:

- (1) You are the original retail purchaser of the product;
- (2) The product was properly installed in a residential dwelling, and;
- (3) The product was made or assembled exclusively from materials and components.

WARRANTY: We warrants the product against original defects in materials or workmanship for one year from the date of purchase. Our sole obligation under the warranty is to repair or replace defective products or components without charge. We is not responsible for transportation costs to or from the retailer or costs for measuring and installing the products. If repairs are made under this warranty, the repairs will be made with like or similar parts. Conditions or damages caused by accidents, alterations, misuse or failure to follow instructions for measurement, installation, cleaning or maintenance are excluded from the warranty. In addition, normal wear and tear is not covered by the warranty. THIS WARRANTY IS EXCLUSIVE AND IN LIEU OF ALL OTHER WRITTEN OR ORAL WARRANTIES OR OBLIGATIONS AND LIABILITIES. No person is authorized to extend or alter this warranty. SHALL HAVE NO LIABILITY WHATSOEVER FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES. Some states do not allow the exclusion or limitation of incidental or consequential damages, so this limitation or exclusion may not apply to you. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state. SERVICE: If you believe a product is defective, please return the product with your original sales receipt to the place of purchase. This store will arrange for inspection of the product and repair or replacement, if warranted. If you need further assistance regarding this warranty, you may write or call at the address or telephone number provided below.

Questions? Let us help!

- Please uninstall the blind and have the following information available for customer service:
- blind's **item number** (located on the ends of the box)
 - blind's **sticker information** (located in the top headrail)
- Providing customer service with this information will help ensure faster service.

1 inch Cordless Vinyl Mini Blind


Instructions for Installation, Operation & Cleaning

Congratulations on your 1 inch cordless vinyl mini blind purchase! You can take pride and comfort in knowing that your new blind will be easy to install, will add to your home's beauty, and will perform to your expectations. Before beginning installation, please take a moment to review the following instructions and safety warnings.

IMPORTANT SAFETY INFORMATION


Read all instructions, warning tags, and labels provided with your product to avoid injury. Keep this manual. Please contact our Customer Service Center at the phone number, email or address on the back of this manual for additional support.

Tools Needed




Time Required: 15 minutes

Items in the Box	Up to 39" Wide	Over 39" Wide
1 Vinyl Mini Blind	1	1
2 Mounting Brackets	2	3
3 Bracket Screws	4	6
4 Wand	1	1
5 Headrail End Caps	2	2
6 Bottomrail End Caps	2	2
7 Hold Down Brackets	2	2
8 Hold Down Bracket Screws	4	4




Installation Instructions


1. Determine inside/ceiling or outside mount.



2. Place blind in desired location and mark corners.



3. Tilt headrail forward and mark location of ladder cord internal components with an "X" (see page 7 for diagram). For proper operation of the blind, brackets must be outside of this area.



NOTE: Make sure bracket is oriented properly before marking bracket hole locations.




Shortening Instructions

Go online to shorturl.at/CHNX8 to watch our step by step instructional shortening videos!

PLEASE NOTE THAT BY SHORTENING YOUR BLIND, YOU ARE VOIDING THE WARRANTY.

PARTS



Tools needed: flat head screwdriver and scissors
Estimated time: 30 minutes

1. Fully lower the installed blind. Determine your desired blind length.


2. Start with the first slat below your desired length. Use scissors to carefully cut diagonally through each route hole. Make sure not to cut the central lift cord or the horizontal ladder cord under the slat. Repeat for all slats until you get to the bottomrail. Do not cut the bottomrail. Remove the cut slats.

3. Use a flat head screwdriver to remove all plugs on the underside of the bottomrail. Note the plug is attached to the lift cord and should remain attached.

4. Cut all vertical ladder cords 2 1/2 rungs below the last slat. Then, cut all horizontal ladder cords EXCEPT for the rung below the last slat. To ensure a level bottomrail, make sure that the same amount of string is cut on each ladder cord. Do not cut the central lift cord. Remove excess ladder cord pieces.

5. Insert the vertical ladder cord strings into the hole on the underside of the bottomrail and secure the plug back into place. Repeat for all plug locations.


TIP: If your blind creeps up, add weight to the bottom rail.



Operating Instructions


TO BRING BLIND DOWN TO WINDOW SILL:

Pull blind down to the window sill by pulling down on the bottom rail. Note: You may pull blind all the way down to the window sill or stop at any desired height.



TO FULLY OPEN BLIND:

Push blind up by pushing up on the bottom rail. Note: You may fully open blind to top of window or stop at any desired height.



TO TILT SLATS:


Twist wand left and right to open and close slats to your preference.




TO CLEAN BLIND:

Dust gently with clean, damp non-abrasive cloth.


4. Mark screw locations. Align edge of bracket inside of marks made in step 2, ensuring to avoid the "X."



5. Drill holes.




6. Screw brackets into place.




7. Attach front lip of headrail into the front hook of each mounting bracket.

- TIP: Ensure the headrail end caps are in place before installing.
- TIP: Be sure headrail is hooked onto all brackets before proceeding to step 8. Do not install blind one bracket at a time.
- TIP: Be sure that the tilt wand connector is facing you and on the left side of the blind when installing.




8. Rotate and push headrail back into the mounting brackets until the back of the headrail clicks into place.

- TIP: More force may need to be applied in order to get blind to click into brackets. Two people may be required, depending on the width of your blind.







9. Insert the hook at the top of the wand through the hole protruding from the front left side of the headrail.



How to Correct an Uneven Bottomrail

1. Fully extend the blind.
2. Pull down hard on the highest side of the bottomrail.
3. Push the bottomrail up to the headrail.
4. Fully extend the blind again.
5. Repeat steps until the bottomrail is level.



OPTIONAL: Hold down bracket installation

Use only if you wish to secure the blind to the bottom of the window.

1. Screw the hold down brackets (one on each side) to the bottom of the window or sill.
2. Insert the pins of the hold down brackets into the holes on the sides of the bottomrail end caps.

