
# 48' Single Filament String Light Set with Remote Control



#### **Parameters**

ETL Certificate No.: GLS22C2YC-S14-15

Total Length: 48FT/14.6M

Power: 4.0W

Input: 120-240V AC, 50-60Hz Power Source: Corded Electric

Light Color: 2700K (Warm White)

Waterproof: Yes

Operation Temperature:-4-104°(-20-40°C)
Controller Reception Mode: Radio Frequency(RF)
Remote Control Battery Type: 1x CR2025 (Included)

## **Package Includes**

1 x 48FT String with 15 Sockets

18 x LED Bulbs (3 Spares)

io x ren prins (9 share

1 x Adapter Controller


1 x Remote Control

1 x User Manual


# Two Ways to Control the Lights

## Operating by String Adapter Controller

The button of the string adapter control can serve as the remote control. Every time you press it once, the string lights will go through 1 mode. When the remote control is missing or out of battery, you can use it to control the light. The adapter control cannot adjust the speed or control the timer.



# **②** Operating by Remote Control



## **NOTES**

- 1. Please shut off the power before installation.
- 2. Under the 7 Dynamic Modes, it is able to adjust the Speed.
- 3. Pressing the timing button causes the string lights to flash, confirming that your setting was successful.
- 4. The memory function recalls the last mode used when the device is turned off, but it is only compatible with the remote control. If you use the adapter control, the string lights will always start in Fade Mode.
- 5. Please ensure the bulbs are screwed in tightly during installation, or they may not light up.
- 6. Speed & timer cannot be controlled through the adapter control.

## A CAUTIONS:

- 1. This product is NOT a toy, To avoid risk of fire, burns, personal injury or electric shock, please install in a place where children cannot reach.
- 2. To reduce the risk of electric shock, DO NOT operate when no bulbs are in the sockets.
- 3. When the string light is used outdoors, please connect to a Ground Fault Circuit Interrupting (GFCI) outlet.
- 4. The string light and the bulbs are waterproof, but the remote control is NOT.
- 5. DO NOT install near gas or electric heaters, fire, candles or any dangerous places
- 6. DO NOT use staples or nails to fix the wiring of the product, or place it on sharp hooks.
- 7. DO NOT place the lamps on the supply cord or any wire.
- 8. DO NOT cover the product with cloth, paper or other objects when in use.
- 9. Unplug when it's not used. Never leave it unattended. When not use, please store in a cool, dry place and avoid sunlight.

## Warranty

- 1. During the warranty period, we offer refunds or replacements at no charge for users who operate the device according to the user manual.
- 2. This warranty does not cover.
- (A) Failure or damage due to the improper use, repair or remodeling.
- (B) Failure or damage because of falling.
- (C) Failure or damage caused by fire, earthquake, flood, lightning and other natural disasters.
- (D) Failure or damage when used other than its intended use.
- (E) Failure or damage caused by the third-party products other than this device.

## **After-Sales Service Guarantee**

We offer a 12-Month warranty for this product from the date of purchase. If you have any problems with the

Note: An order ID with a detailed question description and product images is preferred when contacting our customer service, if possible.

Made in China