

Product Dimension: 100.79" Dia. x 98.82" H.



⚠ SAFETY INFORMATION

- Assemble on a soft surface, such as carpeting, to avoid scratching the pole finish or tearing the umbrella fabric.
- Close the umbrella during windy condition. Do not leave the umbrella open in high winds.
- Use a heavy or weighted umbrella base to stabilize the umbrella.

CARE AND MAINTENANCE

Wash with mild soap and water, rinse with clean water and let air dry.
Always let the umbrella dry completely before storing.

OPERATION INSTRUCTION

Step 1: Connect umbrella with bottom pole by locking the metal pins.

Step 2: Open umbrella by turning the crank to clockwise direction all the way up.

Step 3: Press the button and tilt the umbrella to the desired position.

Step 4: Once the umbrella has been tilted, press the button and set the Umbrella to a level position.

Step 5: Continue cranking in counterclockwise direction to close down the umbrella.

