Model#:BU8982-BK00

SPARE PARTS LIST

Parts Code	Picture	Parts Name	Number
A		Left Armrest	1
B		Righ Armrest	1
C		Cushion	1
D		Seat Metal Base	1
E		Backrest	1

Parts Code	Picture	Parts Name	Number
F		Backrest end cover (longer one)	1
G		Headrest	1
H		Moving Drag Board With Wheels	1
I		Headrest of moving Drag Board	1
J		Reinforcement plate for the front half (short one)	1


Accessory Kit(Packed in a Small Bag)

Parts Code	Image	Parts Name	Qty(Pcs)
1		Straight pin Splitpin	1
2		Small self-attack screws	8
3		M5x30 Preassebled screws	3
		M4x45 Preassebled screws	8
4		Wheels	2


Parts Code	Image	Parts Name	Qty(Pcs)
5		L-shaped screwdriver turning corner	1
6		Wrench	1
7		Hex Wrench	1
8		Standnail	4

Installation Diagram


Step1




Step2




Step3




Step4




Step5




Step6




Step7




Step8



Step9



Step10



Step11

