oneisall
TRANSFORM HOW YOU PET

F1-W Cordless Pet Feeder with WiFi

Model: PF06

User Manual
ON-DI72

Contents

Safety Warning 01
Product Overview 02
In the Package 03
Assemble the Feeder 04
Icon Introduction 06
Connect to APP 08
The Desired Amount of Kibbles 10
Troubleshooting 12
Warranty Information 13
GPSR Product Information 14

Safety Warning

1. Select a stable and firm location to install the feeder to avoid it from shaking or toppling over.

2. Ensure that the installation environment is dry and away from water sources and damp areas.

3. Before adding pet food, check if the food is suitable for feeding to avoid using deteriorated or unsuitable food.

4. Set an appropriate feeding amount and time, and do not overfeed to prevent pet obesity or indigestion.

5. Observe the pet's eating situation regularly and adjust in time if there is any abnormality.

6. Clean the feeder regularly to keep it clean and hygienic and prevent the growth of bacteria.

7. Pay attention to keeping the battery fully charged or the power connection normal.

8. These packaging bags may cause suffocation, Keep them away from children and pets.

9. Do not use the feeder when the pet cannot reach the food plate or has any physical disability.

10. Do not put your fingers into the food outlet or let your fingers touch the rotor.

11. Do not immerse the base part in water at any time, otherwise it may damage electronic components, such as the control panel.

Product Overview



In the Package

Specifications

Product Name:	F1-W Cordless Pet Feeder with WiFi
Model:	PF06
Size:	12.83*7.17*8.29 inches (326*182*235mm)
Capacity:	7L
Rated Voltage/Current:	DC 5V ⎓ 1A
Battery Type:	Built-in lithium-ion battery
Charging Time:	6 Hours
Battery Run Time:	100 Days
Battery Capacity:	5000 mAh
Wi-Fi Frequency:	2.4G Hz
FCC ID:	2BBAWPF0008
Material:	SUS 304 Stainless Steel+ ABS

Assemble the Feeder

1. Open the food tank, and take out the bowl and accessories.

2. Lift the front side of the machine. Insert the plastic bowl holder into the machine, press down and install it.

3. Lay the machine on its side, insert the power cord into the type-C port, and snap the cord into the wire slot.

4. Turn the power switch to the "on" position.

5. Fill the tank with pet dry food and connect the charging cord to the power supply.
Note:
Kibble size allowed: 2-18 mm/0.07-0.7 inch in diameter.
Do not use it for canned food or wet food.



6. Put the desiccant bag into the desiccant box and put the stainless steel bowl on the bowl holder.

Icon Introduction

Operating Guide	
Unlock the Feeder:	Press and hold the dial for 3 seconds
Menu Selection/Adjust Numbers:	Rotate the dial
Setting Confirmation:	Click the dial
Back to Previous Menu:	Double click on the dial

Icon Description	
Feed	Manual feeding. The maximum setting is 12 servings of oat food.
Time	Set the clock time of the feeder device.
Plan	Set the feeding plan for the feeder. The maximum setting is 10 plans.
Mic	When the icon is flashing, press and hold the button to record sound. **Do not support to record a calling message via APP currently.**
Wifi 2.4G	In the case of flashing icon, the feeder can search for and connect to Wi-Fi.
Reset	Clear the device's feeding plan and restart the device.
	Li-ion battery built in.
	When the battery power is low, the device emits a beeping alarm sound.
	Charging reminder for the device. The device is powered by an external charging cable.

Lock

Connect to APP

1. Download and install the Oneisall APP from the app store.

Download on the App Store
GET IT ON Google Play
Oneisall APP

2. Connect the feeder according to the instructions.



- Select the 2.4G Hz Wi-Fi network and enter the password.
- If your Wi-Fi is 5G Hz, please set it to 2.4G Hz First Common Router Settings.
- When connecting to the device, please make sure that the Bluetooth on your mobile phone is turned on.



Program the feeder manually

Program the feeder on the APP

The Desired Amount of Kibbles

Note:
The amount of every portion is not adjustable, Pet owners should adjust the number of portions based on their pet's daily meals and appropriate amount per meal.
The size of the kibble we used in our lab: 0.7 inch. Here's the data from our experiment.

Cup	Portion	Gram
1/8	3	15
1/4	5	29
1/3	7	38
1/2	10	57
1	19	114

This data is for reference only. You need to test out the right amount for your pet, based on the dry food you used.

Here are the steps:

1. For example, 1/4 cup equals to 5 portions, so 1/8 cup would equal to 3 portions.

2. Set the portion number to 5.

3. Measure the delivered kibbles. If the kibbles are measured as the amount you need, it means this setting is OK.

4. Otherwise, adjust the portion number to let it get close to the desired amount.

Troubleshooting

Please attach your troubleshooting and order ID, contact us via email **support@oneisall.com.**
We would help you solve the problem fast.

Problems	Solutions
The feeder can not work	Check if the power switch at the bottom of the device is set to the "on" position.
	Check if the cord is connected well.
	Use another type-C charging cord to see if the feeder works.
Desiccant Replacement	Email us: **support@oneisall.com**
The dial does not work	Try to press and hold it for 3 seconds to unlock the feeder.
Food stuck	Make sure the kibble size is less than 0.7 inch in diameter.
	If the food stop in the outlet, clean it.

Warranty Information

Oneisall offers a standard 2-year warranty.If you have any issues with your Oneisall product, please do not hesitate to contact us. Be sure to include your proof of purchase, model number, and any relevant photos or videos in your message to expedite the process. Our Oneisall support team is available 7 days a week and will respond to your inquiry within 24 hours. Thank you for choosing Oneisall.

Please note that the Oneisall warranty does not apply to used products or purchases made from unauthorized sellers. It's important to be aware that the warranty also does not cover consumable parts such as blades, guards, filters, brushes, and similar items. These parts may require regular replacement or maintenance.

support@oneisall.com
+1877-522-6578(US)Mon-Fri 8am-5pm(PST)
www.oneisall.com

Oneisall Support

@Oneisall Official

GPSR Product Information

UK REP

Name: APEX CE SPECIALISTS LIMITED
Add: 5F East Union Street, Manchester, England, M16 9AE
Contact: Wells
Tel: +44161 3170130
E-Mail: Info@apexce.com

Product Name: F1-W Cordless Pet Feeder with WiFi
Brand: Oneisall
Product Model: PF06
Input: DC 5V ⎓ 1A

GPSR Manufacturer Information
Business Name: chuntougongyiyouxiangongsi
Manufacturer Address: CN, 231200, anhui, chuzhoushi, laianxian, xinmindaqiaolu, laianxiangzhongyuanlongdiandayuan2403shi
Tel: +86 130 4980 3766
E-Mail: oneisallofficial@hotmail.com

Made in China

oneisall
TRANSFORM HOW YOU PET

Any problem you have, please contact us:
support@oneisall.com

Download Manual

ON-DI72

PF06 WIFI款喂食器说明书
尺寸：105X140mm
材质：128g双铜
印刷：封面封底：四色印刷
内页：黑白印刷
折叠方式：骑马钉

C0 M63 Y100 K0