




Assembly Instruction

DINING CHAIR


| PART LIST | | | | HARDWARE LIST | | | | |
|-----------|------------|---|-------|---------------|---------------|---|--------------|-------|
| A | FRONT LEG |  | 2 PCS | 1 | BOLT-SMALL |  | 5/16"X2" | 4 PCS |
| B | REAR LEG |  | 2 PCS | 2 | BOLT-LARGE |  | 5/16"X2-1/2" | 4 PCS |
| C | CHAIR BACK |  | 1 PC | 3 | SPRING WASHER |  | 5/16" | 8 PCS |
| | | | | 4 | WASHER |  | 5/16"X19mm | 8 PCS |
| | | | | 5 | ALLEN WRENCH |  | 5mm | 1 PC |

STEP 1

Fix front leg with chair back



STEP 2
Fix rear leg with chair back



STEP 3
Assembly completed

