

3 LIGHT FLOOR LAMP WITH WHITE FABRIC SHADES

WARNINGS AND CAUTIONS

CAUTION: TO PREVENT ELECTRIC SHOCK, MATCH WIDE BLADE OF PLUG TO WIDE SLOT, FULLY INSERT.

This portable lamp has a polarized plug (one blade is wider than the other) as a feature to reduce risk of electric shock, this plug will fit in a polarized outlet only one way. If it does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless the plug can be fully inserted. Do not alter this plug. Save these instructions for future reference.

PREPARATION

Before beginning assembly and installation of product, make sure all parts are present. Compare parts with package contents list and diagram above. If any part is missing or damaged, do not attempt to assemble, install or operate the product. Contact customer service for replacement parts.

Lay out all lamp parts from box and put them on a flat surface.

ASSEMBLY AND INSTALLATION INSTRUCTIONS

Start assembly from top to bottom:

1. Screw top portion of lamp (A) onto pole (B) clockwise to tighten. Pull any excess cord gently through the poles so that these parts fit.
2. Screw pole (B) into pole (C) clockwise to tighten.
3. Screw pole (C) into pole (D) clockwise to tighten.
4. Screw pole (D) onto lamp base (E) clockwise to tighten
5. Insert lamp shade (G) onto lamp socket (F)
6. Tighten lamp shade (G) with socket nut (H). **If the socket nut is already screwed into the lamp socket (F), you will need to unscrew the socket nut (H) from the lamp socket (F) before you insert the lamp shade (G).**
7. Install light bulbs. Only use bulbs of the specified type and maximum rated wattage or less.

CARE AND MAINTENANCE

Clean with soft dry cloth. Do not use abrasives.

Bulb replacement:

Use a 25W type E26 medium base incandescent bulb, or LED bulb equivalent (not included)

Shut off main power supply before replacing bulbs

PARTS IDENTIFICATION

- A. Top portion of lamp
- B. Pole
- C. Pole
- D. Pole
- E. Base
- F. Lamp Socket
- G. Lamp Shade
- H. Socket Nut (All ready screwed into lamp socket (F))

