

Installation instructions for bathroom cabinet




PRODUCT LIST









X3




PRODUCT LIST 1

Name	Part	Qty.
A		68
B		68
C1		8
C2		8
E	 Large bend hinge	4
F	 4*14	56

Name	Part	Qty.
G		6
I		2
M	 3.5*30	1
N	 4*24	12

Slides Must Be Separated Before Assembly.
After Separated, Set Aside Until Needed for Assembly.



The guide rail needs to be divided into two parts: C1 and C2.


MPORTANT INFORMATION PLEASE REA CAREFULLY

∗Please follow the assembly instructions precisely anduse the product accordingly


∗Please wear gloves, open the item slowly and cautiously to avoid pinching your hands by metal joints.

∗After receiving the product, please check the quantity of plates and accessories first. If you find any missing items, please contact customer service as soon as possible;


∗During installation, all accessories cannot be disassembled and mixed together at one time. It is recommended to take out the required number of accessories from the bag according to each step in the instructions;




Tighten quickfit until shoulder is flush with panel.Do not overtighten or undertighten.



When fitting cam lock, ensure starting position is correct before you insert connecting quickfit.




head should be in the centre of the cam lock when the two panels are joined.




Turn cam lock clockwise to tighten.


Step 1




Step 2



Step 3




Step 4




Lock with 4.0x14
self-correcting screws


Step 5




Step 6




Step 7



Step 8




Step 9




Lock with 3.5x30
self-correcting screw
Lock the 2 plates
from the bottom.


Step 10




Step 11





Note: The hinges
of the middle two
cabinet doors are flat.







Step 12






Step 13






Step 14



Step 15



CARE CLEANING AND MAINTE NANCE

1.Dust regularly with a soft, dry cloth.
2.Avoid the use of all chemicals household cleaners, abrasives, or cleaners that contain lemon, vinegar, or other acids that may damage the finish.
3.E xcessive exposure to sunlight and extreme changes in temperature and moisture can damage wood furniture.
4.The sink top is resilient, but care needs to be taken to preserve its appearance.
5.Do not place hot appliances, such as curling irons and hot hair dryers directly on the countertop. Wipe spills immediately.