


① NOTICE Please retain these instructions for future reference.

- Firmly secure all screws before use.
- Product is intended for indoor use only.
- Do not place this tree in a wet location.
- This seasonal product is not intended for permanent installation or use.
- Do not use or store this item in the proximity of open flame, flammable/combustible chemicals, or other strong heat sources.
- If any parts are missing, broken, damaged, or worn, stop using this item until repairs are made and/or factory replacement parts are installed.
- Do not use this item in a way inconsistent with the manufacturer's instructions as this could void the product warranty.

PARTS



Please remove the caps on the end of the poles before assembly.

PRODUCT ASSEMBLY

Assemble the tree.

NOTE: Bottom section is wider than the middle section. Make sure sections are arranged in the correct order.



1 PERSON ASSEMBLY



UP TO 30 MIN. ASSEMBLY

SHAPING INSTRUCTION

How to fluff the branches

Shaping the tree branches is the last step of assembly. The care and attention given to this final process will result in a genuinely beautiful and appealing holiday centerpiece.

13

Every tree style is shipped from the factory with the tips of each branch compressed to the center (Fig.1)



Fig.1

Each branch tip must be shaped to its proper position to give the tree natural look. Spread tips away from the branch gently (Fig.2)



Fig.2

Each individual tip should be spread out separately. Tips should be bent slightly upward to add a more natural looking appearance (Fig.3).




Fig.3

CLEANING & STORAGE

- Store this tree in a cool and dry place away from heat and moisture.
- Before putting this tree in storage, do the following:
 - Completely remove all decorations.
 - Clean the tree with a slightly damp cloth and let it dry naturally.
 - Raise all branches to original upright position; make sure not to damage any branches in the process.

