
ASSEMBLY INSTRUCTION

meridian furniture

SKU / ITEM# 33012-33013-33014-33018-33019-33020

Accent Chair



+ Do Not Use Power Tools



+ Suggested Adults




NOTE: For questions about parts or assembly please email support@meridianfunitureusa.com or call us at 718-758-4455.


1 Read instructions cover to cover.
2 Save all packinging until assembly is completed

+ Parts Included


1 Backrest (1pc)




2 Seat cushion (1pc)



3 Left leg (1pc)



4 Right leg (1pc)



1 IMPORTANT SAFETY INFORMATION

Do not assemble the product if any of the following parts arrived damaged:
Part 1 - Backrest
Part 2 - Seat cushion
Part 3 - Left leg
Part 4 - Right leg
Do not assemble if any of the following hardware parts are missing:
Part A - Bolt 5/16 x 50 mm
Part B - Spring washer
Part C - Flat washer
Part D - Allen Key
Part E - Wood plug

2 IMPORTANT ASSEMBLY INFORMATION

Assembly Step: If loosening persists,please make sure to tighten all the bolts periodically,or use a thread locker adhesive.

+ Hardware Included

Ⓐ Bolts 5/16 x 50mm (6pcs)



Ⓑ Spring washer (6pcs)



Ⓒ Flat washer (6pcs)



Ⓓ Allen Key (1/pc)



Ⓔ Wood plug (2/pcs)




Hardware : Each of the above hardware including extra 1pc.

ASSEMBLY INSTRUCTION


SKU / ITEM# 33012-33013-33014-33018-33019-33020

Accent Chair


1



2



3



The assembly of the chair is complete

NOTE: For questions about parts or assembly please email support@meridianfunitureusa.com or call us at 718-758-4455.