















User's Manual













PRODUCT PARTS:


A	B	C	D	E	F
					
1PC	1PC	1PC	2PCS	1PC	1PC
G	H	I	J	K	L
					
1PC	1PC	1PC	1PC	1PC	1PC
M	N				
					
1PC	1PC				

HARDWARE:

①	②	③	④	⑤	⑥
					
1/4"x25mm	Ø8x30mm	Ø6x30mm	Ø6x33mm	Ø15x9mm	
16+1 PCS	14+1PCS	18+1PCS	12+1 PCS	12+1 PCS	4 PCS
⑦	⑧	⑨	⑩		
					
	Ø4x12mm		5/32"x15mm		
2PCS	12+1PCS	1PC	2PCS		


STEP 1

- ②  10pcs
Ø8x30mm




STEP 2

- ②  4pcs
Ø8x30mm




STEP 3

- ①  5pcs
1/4"x25mm




STEP 4

- ①  5pcs
1/4"x25mm







STEP 5

- ①  6pcs
1/4"x25mm





STEP 6

- ③  8pcs
Ø6x30mm
- ④  2pcs
Ø6x33mm




STEP 7

- | | |
|---|---|
|  4pcs
Ø6x30mm |  4pcs
Ø6x33mm |
|---|---|





STEP 8

- | |
|---|
|  6pcs
Ø6x30mm |
|---|




STEP 9

5  2pcs
Ø15x9mm




STEP 10

5  2pcs
Ø15x9mm



STEP 11


5  2pcs
Ø15x9mm




STEP 12

4  6pcs Ø6x33mm


7  2pcs

8  4pcs Ø4x12mm




STEP 13

5  6pcs
Ø15x9mm







STEP 14

8  8pcs
Ø4x12mm


Three-way adjustable hinge for perfectly aligned doors


1. TO ADJUST DOOR FORWARD OR BACKWARD.
2. TO ADJUST DOOR TO RIGHT OR TO LEFT.
3. TO ADJUST DOOR UP OR DOWN.



x2



STEP 15

- | | | |
|---|---|--------------------|
| ⑨ |  | 1pc |
| ⑩ |  | 2pcs
5/32"x15mm |




STEP 16

- | | | |
|---|---|------|
| ⑥ |  | 4pcs |
|---|---|------|




STEP 17



To install the Top (1) to the vanity (2). Apply silicone caulk to the top edge of the wood cabinet. With the help of another adult, gently lower the Sink top with assembled sink onto the cabinet. Make sure the Sink top is flush with the back side of the wood cabinet and the wood cabinet left and right side walls.

STEP 18



IMPORTANT-READ CAREFULLY-RETAIN FOR FUTURE REFERENCE

WARNING:

- Children must stay away from the assembly zone, preventing children from potential asphyxia because of plastic bag and foam breathing in nose;
- For your safety, please do not tread or climb product.
- The loading weight shall be within the range that vendor claims. The product is designed for adults use, domestic use and indoor use only.
- The product shall not combine with other product for use.
- If the product with seat height adjustments with energy accumulators that only trained personnel may replace or repair seat height adjustment components with energy accumulators
- Check regularly that all assembly fastenings are properly tightened, do not use the product if any structural part is broken or missing
- Incorrect installation and incorrect use can cause accidents. Please completely follow the guidance of assembly instruction.

Security instructions:

- Before assembling check whether all parts listed in the parts list have been delivered. Do not start assembling if parts are missing or damaged.
- A failure to assemble this product correctly could cause damage or result in serious injury! Before assembling make sure that you have enough space for the procedure. Assemble on a flat surface.
- Keep the assembly instructions available at all times and follow each of the individual steps exactly.
- During assembly, be careful with all the parts of the assembly (do not walk on them or distort them) and beware of shearing and trapping risks. Keep children and pets away while setting up the furniture.