ASSEMBLY INSTRUCTIONS



Attention: Please remove mattress from the bed should you wish to clean the floor under the bed. Dragging the bed around with mattress might compromise the bed construction, stability or cause permanent damage.

In the unlikely event parts are missing or damaged in transit

Please contact the seller on the website your purchanse was made.
Our customer service team will assist.
We are able to arrange replacement parts to complete assembly.

PART LIST



HARDWARE LIST

Label	Picture	Description	Qty	Label	Picture	Description	Qty
A		Single Plastic CAP	26	H		Bolt M6x20	4
B		Double Plastic CAP	13	I		Screw 5*40	8
C		Bolt M8x20	16	J		Bolt M8x30	8
D		Screw 4*35	4	K		Bolt M8x15	22
E		Washer M8	8	L		Connection Plate Left	2
F		NUT	4				
G		Screw 4*80	6	R		Connection Plate Right	2

TOOL list

Label	Picture	Description	Qty
T-1		Screw driver (not provided)	1
T-2		Allen key M5	1
T-3		Allen key M4	1
T-4		Spanner	1

Step 1

I 8pcs Screw 5*40	T-1 1pc Screw driver (not provided)



Step 2

H 4pcs Bolt M6x20	13 2pcs Corner Bracket	L 2pcs Connection Plate Left	R 2pcs Connection Plate Right
		C 16pcs Bolt M8x20	T-2 1pc Allen key M5
		E 8pcs Washer M8	T-3 1pc Allen key M4



Step 3



G 6pcs Screw 4*80	T-2 1pc Allen key M5
J 8pcs Bolt M8x30	T-1 1pc Screw driver (not provided)

Step 4

K 16pcs Bolt M8x15	T-2 1pc Allen key M5



Step 5

K 6pcs	T-2 1pc
Bolt M8x15	Allen key M5



Step 6 Attach Non woven fabric

Turn bed on its side and attach Non-woven fabric 20 to base.



Step 7

D 4pcs Screw 4*35	T-1 1pc Screw driver (not provided)



Step 8

A 26pcs Single Plastic CAP	B 13pcs Double Plastic CAP



Step 9

F 4pcs	T-4 1pc
NUT	Spanner



NOTE: Do Not Overtighten

Step 10



IMPORTANT NOTICE

OTTOMAN OPERATING INSTRUCTIONS

Once your bed frame is completely assembled the slat unit will not operate correctly unless a mattress is placed on the slat frame. Position the mattress on the slat frame whilst it is in the closed position.

Operate the strap handle to open and close the ottoman. PLEASE NOTE - it takes a lot of force to make the initial movement of the ottoman. This is a design feature of the product so it does not fall shut - the nearer to being closed the ottoman is, the easier it is to move. When the ottoman is almost shut it will close completely under its own weight.

When lowering the slat unit for the first time, take care to make sure it does not rub unevenly on the inside face of the side rails. If it does, the bed has been assembled slightly out of square. This can be reflected by moving the foot end of the bed slightly to the left or right whilst leaving the head end stationary.

PISTONS

The pistons used in the construction of this product are extremely strong and cannot be operated by hand when taken off the ottoman. All pistons are tested for correct pressure and operation before being attached to the slat unit.

Initially it might appear that the pistons are very stiff when opening and closing the ottoman - THIS IS PERFECTLY NORMAL.

After operating the ottoman a few times, the movement of the pistons and the opening and closing of the ottoman will become easier.

WARNING

For the safety of yourselves and others, please ensure that:

- Only the handle is used when lifting and lowering the frame. Failure to comply with this warning may result in injury and finger entrapment.
- The handle is attached and always left visible on the outside of the bedstead frame.
- The metal frame is fully raised in the full 'Up' position before using the ottoman space, otherwise the frame could close (fall) or open (spring up) causing injury.
- Children and pets are not left unattended when the frame is in the lifted position as they could become trapped inside the ottoman space.
- Please keep children and pets away from the ottoman bedstead whilst opening and closing the slat frame to avoid injury.
- The items store under the bed - i.e. the top of an item must not touch the underside of the mattress metal frame base or it may get damaged.

Hints and Tips

Failure to do so may result in injury.

To operate the ottoman, always use two hands at arm's length to push down on the bed frame end, in between the 2 rows of slats (as shown below) to close the bed frame.

To open, lift up using the nylon strap on the bed end.
You must always ensure the mattress is on the bed frame before lifting to open and close the bed frame.

The weight of the mattress loaded on the frame helps to close the bed frame easier and with less effort, also keep the frame in closed position until it is pulled upwards by user.



Always ensure Mattress is on the bed frame



Hints and Tips

Failure to do so may result in injury.



Bed frame must be in CLOSED position,
with Mattress on the bed when moving the bed.