



LUNAR ROVER

Installation instruction

► Assembly Parts List

A.  *11 B.  *11 C.  *11 D.  *1

► Assembly Diagram



Please align and tighten in sequence as shown in the above figure