






# WINCHESTER ASSEMBLY INSTRUCTIONS



## PARTS LIST


| LABEL | PICTURE                                                                           | DESCRIPTION | QTY |
|-------|-----------------------------------------------------------------------------------|-------------|-----|
| A     |  | Left Desk   | 1   |
| B     |  | Right Desk  | 1   |

## HARDWARE

| LABEL | PICTURE                                                                             | DESCRIPTION                  | QTY |
|-------|-------------------------------------------------------------------------------------|------------------------------|-----|
| 1     |  | Allen Bolt<br>M5/16"*1-9/16" | 6   |
| 2     |  | Spring washer<br>M5/16*Ø13mm | 6   |
| 3     |  | Flat washer<br>M5/16*Ø19mm   | 6   |
| 4     |  | Allen Key<br>4mm             | 1   |


## ASSEMBLY STEPS

STEP 1: Attach the Left Desk (A) on the Right Desk (B)



-  **Read instructions cover to cover**
-  **Have two adults on hand for assembly**
-  **Do not assemble on flooring or carpet. Assemble on a clean non - marring surface (ex: packing foam)**
-  **Save all packing until assembly is completed**

Complete



## CARE & MAINTENANCE



Do not put hot items directly on furniture surface.



Do not clean furniture with harsh cleansers or polish.



Dust and wipe up spills using a clean, non-colored, lint-free cloth.



Stains may be removed with a mild soap solution and a damp cloth.



Do not place furniture under direct sunlight.



Do not place furniture near heating or cooling vents.



Do not write on furniture without a padded barrier to protect the surface.



Do not place furniture outside, for indoor use only