


Chocolate Two Door TV Console



Hardware List






Item	Description	Qty
a	Bolt 1/4"*1-1/8"	4 PCS
b	Allen wrench	1 PC
c	Washer 1/4"*12mm	4 PCS
d	Shelf Metal Clip	16 PCS
e	Left Door Pull	1 PC
f	Right Door Pull	1 PC
g	Machine screw for door pull 5/32" X 3/4"	2PCS

Parts List

Item	Description	Qty
A	Cabinet	1 PC
B	Top Panel	1 PC
C	Side Panel	2 PCS
D	Middle Bottom Panel	1 PC
E	Side Bottom Panel	2 PCS
F	Middle Adjustable Shelf	2 PCS
G	Side Adjustable Shelf	2PCS

Assembly Instructions

Two person assembly recommended.

<p>Step 1 Unfold the cabinet.</p> 	<p>Step 2 Open 2 doors. Insert the middle bottom panel first, and then insert side bottom panels.</p> 
<p>Step 3 Insert two side panels.</p> 	<p>Step 4 Fasten the top with 4 bolts.</p> 
<p>Step 5 Install shelf clips and insert shelves.</p> 	<p>Step 6 Install door pulls.</p> 