




- |                                  |                              |
|----------------------------------|------------------------------|
| (D) Montageanleitung             | (GB) Assembly Instructions   |
| (FR) Notice de montage           | (IT) Istruzioni di montaggio |
| (NL) Handleiding voor de montage | (PL) Instrukcja montażu      |
| (CZ) Montážní návod              | (SK) Návod na montáž         |
| (HU) Szerelési útmutató          | (RO) Instrucțiuni de montaj  |
| (TR) Montaj talimatı             | (RU) Инструкции по монтажу   |





2-2,5

1



		ŠP		V 3x13	
		x8		x16	
H 6,3x13	W	YA 4x27	DA	D	LM
x16	x2	x4	x4	x4	x10
DB L-185mm	ZF	W6 L-997mm	ZB	X	ZC
x2	x4	x1	x8	x8	x23
S L-1867mm	N 3x20	A 8x32	T	ND 3,5x16	B
x1	x42	x40	x2	x16	x4
YD 7x50	WB	GLUE	C	Z	ZG
x20	x1	x1	x4	x4	x20



2

