ASSEMBLY INSTRUCTIONS


Instructions:

1. Insert the Harp (C) into the Saddle (E).

2. Put the Shade (B) onto the Harp (C).

3. Put the Finial (A) onto the Harp (C) to tighten .

4. Please Screw (1)3-Way 150 Watt Bulb into Socket (D).



IMPORTANT SAFETY INSTRUCTIONS

THIS PORTABLE LAMP HAS A POLARIZED PLUG(ONE BLADE IS WIDER THAN THE OTHER)AS A SAFETY FEATURE TO REDUCE THE RISK OF ELECTRIC SHOCK.THIS PLUG WILL FIT IN A POLARIZED OUTLET ONLY ONE WAY.IF THE PLUG DOES NOT FIT FULLY IN THE OUTLET,REVERSE THE PLUG.IF IT STILL DOES NOT FIT,CONTACT A QUALIFIED ELECTRICIAN.NEVER USE WITH AN EXTENSION CORD UNLESS PLUG CAN BE FULLY INSERTED.DO NOT ALTER THE PLUG.