

ASSEMBLY INSTRUCTION

ITEM: N715P491295


DINING TABLE



IMPORTANT NOTE :



- ① PLACE ALL PARTS ON A CLEAN AND SMOOTH SURFACE SUCH AS A RUG OR CARPET TO AVOID THE PARTS FROM BEING SCRATCHED.
- ② BEFORE YOU BEGIN , KINDLY FOLLOW THE ASSEMBLY INSTRUCTIONS STEP BY STEP.
- 3 DO NOT TIGHTEN ALL SCREWS AND BOLTS UNTIL THE TABLE IS FULLY SET-UP

Detail view




Part List

Hardware List


Ⓐ  Table Top (1pc)	①  Ø1/4" x 55mm Bolt (4pcs)
Ⓑ  Frame Table Legs (2pcs)	②  Ø1/4" x 40mm Bolt (2pcs)
Ⓒ  Table apron (1pc)	③  Ø1/4" x 30mm Bolt (16pcs)
	④  Ø1/4" x 13mm x 1.5mm Spring Washer (22pcs)
	⑤  Ø1/4" x 16mm x 1.5mm Flat Washer (22pcs)
	⑥  4 x 58mm Allen key (1pc)


Step 1



3	Ø1/4"x30		16PCS	5	Ø1/4"x16x1.5		16PCS
4	Ø1/4"x13x1.5		16PCS	6	4x58		1PC

Step 2



1	Ø1/4"x55		4PCS			
2	Ø1/4"x40		2PCS	5	Ø1/4"x16x1.5	 6PCS
4	Ø1/4"x13x1.5		6PCS	6	4x58	 1PC

Step 3



Completed