

WARRANTY

Order ID: _____

Purchase Date: _____

Seller name: _____

Add.: 2691 Richter ave Suite123,Irvine CA 92606


Tel: 323 831 2020

Email: Paraheeter@outlook.com

If the number you called is busy or not answered, please do not hesitate to contact us via email, we will reply within 12 hours.

Electric Heater

MODEL:PAR-15D



USER'S MANUAL

Please read the user's manual carefully before use and keep it for future reference!

Sincerely thank you for purchasing our products. This manual contains important safety information concerning the maintenance, use and operation of this product. Failure to follow the instructions contained in this manual may result in serious injury. If you are unable to understand the contents of this manual, please bring it to the attention of your supervisor. Do not operate this product unless you have read and understood the contents of this manual.

WARNING

We are not responsible for any damages resulting from failure to comply with the following instructions.

IMPORTANT SAFETY MEASURES

1. To avoid overheating, do not cover the heater with anything including dust, salt, chemical liquid, etc.

Note: If the heater is used in a humid environment or areas with high salt content in the air, please check whether there are any crystalline solids on the surface of the cover or heating element before turning it on. If there is, do not use it, or stop using it immediately and disconnect the power. After the heater is cool completely, remove the crystalline solid on the surface. The heater can only be used again when there is no crystalline solids on the surface of the cover or heating element as well as clean and dry.

CLEANING&MAINTAINS

1. Always turn off and unplug the heater before cleaning.
2. To clean the heater, use a damp cloth and make sure to dry the remaining water once cleaned.
3. Do not use powerful abrasives or solvent cleaners to clean the heater as they may damage the plastic parts.
4. When not in use, take the heater off and store it carefully in a safe and dry place out of the reach of children.
5. Do not touch the heating unit with your fingers, as the dirt on your hands may affect the lifetime of the heating unit. If you accidentally touch it, remove the finger marks with a soft cloth with alcohol.
6. The heater does not contain user-serviceable parts and must be returned to the manufacturer or its agent if the product is damaged or defective.

Power Button Operation:

1. When the heater is power on, it will come out the sound of "tick";
2. Press the power button on the display screen for the first time, it will show "--", which means the heater is turned on;
3. Press the power button on the display screen for the second time, it will show "Lo", which means the heater is working in low condition;
4. Press the power button on the display screen for the third time, it will show "Hi", which means the heater is working in high condition;
5. Press the power button on the display screen for the fourth time, it will be turned off.

2. The distance between the heater and all kinds of combustible material should be at least 1.5 meters.
3. To avoid possible electric shocks, do not place the cable, plug or appliance in water or in any other liquid. Do not insert screwdrivers or metallic items inside the appliance.
4. If the power cable is damaged, it must be replaced by the manufacturer, its service technician or by someone else authorized by the manufacturer. In the event of handing of appliances by non-authorized people, the guarantee will immediately cease to be valid.
5. Do not use appliances if they are damaged.
6. Do not allow children to use the electrical appliance. Do not leave the appliance unattended when in use close to children.
7. Children less than 3 years old should be kept away unless continuously supervised.
8. **CAUTION** — Some parts of this product can become very hot and cause burns. Particular attention has to be given where children and weak people are present.
9. This heater must be used properly on a grounded outlet.
10. Do not dispose of this product as unclassified municipal rubbish. Due to the use of electrical and electric parts, this product must be collected separately.
11. In order to avoid scalding, it's forbidden to touch the heater when it's working.


12. To avoid possible electric shocks, do not place the heater in bathrooms or similar indoor locations.
13. Turn off all switches and unplug the heater if an emergency situation occurs.
14. The power supplied to this unit must comply with electrical requirement on its label. Damage or fire may result if the incorrect power used.
15. Do not use the heater in somewhere with flammable objects, gas, dust.
16. Please contact with seller if it does not work properly. Do not try to repair the heater by yourself.
17. Please contact the seller if you find other problems not covered in this operation manual.

SPECIFICATION

Model	PAR-15D
Voltage	120V~ /60Hz
Power	1500W
N.W.	7.3LBS
Size	30.3x6.3x3.1 Inches

Remote Control Operation:

Icon	Name	Operation Instructions
1	Power Button	Turn on/off
2	Low Button	Change the heater to low condition (900W)
3	High Button	Change the heater to high condition (1500W)



1. Press power button “1”

① Press the power button “1”, and the display screen of the heater will show "--", which means the heater is turned on. Press the power button “1” again, and the heater will be turned off.

2. Press low button “2”


① When the heater shows "--" or is on, press low button “2”, and the display screen will show “Lo”, which means the heater is working in low condition.

3. Press high button “3”


① When the heater shows "--" or is on, press high button “3”, and the display screen will show “Hi”, which means the heater is working in high condition.

AFTER INSTALLATION

Place Keep the heater at least 50CM(1.67ft) from other things
recommend suspension height: 5-6ft



LIST OF ACCESSORIES




INSTALLATION

Please check all the items against the parts list after opening the box. Only all the items are complete, the installation could be followed.


Step 1

Take the expansion rubber and screws out of the accessory bag. Drill four holes with a diameter of 8mm on the wall. The hole depth is 70mm, and the distance between two vertical holes is 32mm, and horizontal($300\text{mm} \leq L \leq 450\text{mm}$). Install the expansion rubber to the hole, and then take the wall bracket from the accessories. Fix it to the wall with a 5*60 screw.



Step 2


Place the wall bracket on the screw on the back of the heater, and then adjust the wall bracket to the proper position with the nut from the accessory bag to lock it and make sure it will not loosen.



5

Step 3

Match the wall bracket mounted on the back of the heater and the wall, adjust the heater to a suitable position, and lock it with the nut and screw from the accessory to ensure that it will not loosen.



6