


ASSEMBLY INSTRUCTION

Dining Chair



ASSEMBLY INSTRUCTION


Please read these instructions fully before starting assembly:

1. Place all wooden parts on a clean and smooth surface such as a rug or carpet to avoid scratching the parts.
2. Kindly follow the assembly instructions step by step.
3. Do not tighten all screws and bolts until the table is fully assembled.
4. Unscrew the protective plastique supports from the metal insert of the table legs before assembly.
5. Parts of the assembly will be easier with 2 people.

Care and maintenance:

Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.


ASSEMBLY INSTRUCTION



ASSEMBLY INSTRUCTION


Part List For 2

Ⓐ



CUSHION SEAT (2 pcs)

Ⓑ




CHAIR BACK (2 pcs)

Ⓒ




LEG LEFT (2pcs)

Ⓓ




LEG RIGHT (2pcs)

Ⓔ



LEFT+RIGHT SIDE STRETCHER (4pcs)

Ⓕ




FRONT STRETCHER (2pcs)

ASSEMBLY INSTRUCTION

Hardware List For 2


①



Ø 1/4" x 40mm

BOLT (4pcs)


②



Ø 1/4" x 55mm

BOLT (8 pcs)


③



Ø 1/4" x 75mm

BOLT (8 pcs)


④



Ø5/16" x 13mm

LOCK WASHER (20 pcs)

⑤



Ø5/16" x 19 x 2mm

FLAT WASHER (20 pcs)


⑥



4mm

ALLEN KEY (2 pcs)

⑦




Ø4 x 38 mm

WOOD SCREWS (12 pcs)


ASSEMBLY INSTRUCTION


STEP 1:



BOLT Ø 1/4" x 40 mm	BOLT Ø 1/4" x 75 mm	FLAT WASHER Ø5/16" x 13 mm	LOCK WASHER Ø5/16" x 19 x 2mm	ALLEN KEY 4 mm
				
①x2	③x4	④x6	⑤x6	⑥x1


STEP 2:



WOOD SCREWS Ø4 x 38 mm

⑦x2

ASSEMBLY INSTRUCTION

STEP 3:



COMPLETE

