



WF308348

ASSEMBLY INSTRUCTION




PART




PART LIST

(A)



Seat Frame x 1

(B)



Back Frame x 1

(C)




Seat Cushion x 1

(D1)




Left Leg x1

(E2)




Right Armrest x 1

(E1)



Left Armrest x 1


(D2)



Right Leg x1


WF308348

HARDWARE LIST


①  Bolts 1/4"*40mm x 12	②  Spring washer 1/4"*11mm*1.5mm x 12	③  Flat Washer 1/4"*14mm*1.5mm x 8	④  Allen Key 4mm*60mm x 1	⑤  Wood plug 14.5*7 x 8	⑥  Flat Washer 1/4"*16mm*1.5mm x 4
---	--	---	---	---	---

Step 1: Place all parts on a clean, smooth surface.

Attach Seat Frame (A) and Leg (D1,D2), use Bolt (1), Spring washer (2) and Flat washer (6) and use Allen key (4) to tighten its



Step 2: Attach Seat Frame (A) and Armrest (E1,E2), use Bolt (1), Spring washer (2) and Flat washer (3) and use Allen key (4) to tighten its. And attach the wood plug (5).



Step 3: Attach Back Frame (B), Seat Frame (A) and Armrest (E1,E2), use Bolt (1), Spring washer (2) and Flat washer (3) and use Allen key (4) to tighten its. And attach the Wood plug (5).

