




ASSEMBLY INSTRUCTION

WARNING: Suitable for children of 1+ years old; Max weight: 30 kg.

IMPORTANT, RETAIN FOR FUTURE REFERENCE: READ CAREFULLY.

Please Note:

ADULT ASSEMBLY REQUIRED.

- Keep these instructions for future reference.
- Prior to assembly, this package contains small parts. Keep away from children until assembled.
- To prevent serious injury, children must not use the equipment until properly installed.
- Adult supervision required. Do not leave children unattended.


WARNING

- Only allowed for adults to install, keep children away.
- To be used under the direct supervision of an adult.
- Keep away from fire! Keep away from water!
- This product contains small parts and a packaging bag inside. Keep away from small children when unassembled.
- Once installed, adult supervision is required when in use.
- This product is for domestic household use. Place safety mats around the equipment when using it. Children must be under adult supervision to ensure safety.
- Maximum load: 30kg.
- Place this equipment on a level surface, at least 2m from walls, fences, electrical wires and other obstructions.
- Ensure there is at least 200mm of space between the swing and floor.
- Do not install this equipment on concrete, asphalt or other hard surfaces.
- Keep away from direct sunlight.
- Keep this manual safe for future reference.
- Do not modify (e.g., adding accessories) this equipment, unless recommended by the manufacturer.


Maintenance

Periodically check the main parts (cross beams, suspensions, anchors, etc) to ensure they are tight and are in good working condition. Follow these steps when checking this equipment:


- a) Ensure all nuts and bolts are tight.
- b) Oil all metallic moving parts to prevent rust.
- c) Check coverings for bolts and sharp edges - replace when needed.
- d) Check swing seats, chains, ropes and other attachments for any damages or deterioration.
- e) Replace defective parts by following the manufacturer's instructions.
- f) Keep all instructions and parts relating to this product for future reference.
- g) If any problem occurred, please sent it to qualified maintainer.
- h) Clean your toy with a clean damp cloth.




ABx2




x1




ABx2




x1




x2




x3











x2




x2




x2







x1

R**S**

ABx1

T

x1

U**V**

x1




x1

W**X****Y**







x1



x1+1(spare)




x4+1(spare)

 x1	 10*20mm x1	 x13+1(spare)	 x10+1(spare)	 x55+2(spare)
 x28+2(spare)	 x1	 x4+1(spare)	 x1	 x2+1(spare)
 x1	 x1	 8*35mm x1	 x1	 x1
 x2	 M10 x1	 x2		


01

e X2	g X2
	




x2

02




x2

e X 12




x2

d X 4




d X 5




c X 2




d X 8






c X 2




b X4



R



S



b X3




Y X4




W X1





X X1




Y



c X 4	s X 2
	



d X 6



d X 6




m X 1



n X 1



p X 1



d X 6




M

P

P

H


G




d X 10




c X 2




b X 6	j X 2
	



d X 10	a X 1	r X 1
		





Dear Customer:

Thank you so much for your purchase and trust in our Kid Slide Combination.

We provide good After-sales Service for the product.

If you have any doubt about the product or installation problem,

please contact our After-sales staff first, we are happy to help you and will reply within 24 hours.