







ASSEMBLY INSTRUCTION

<p>Ax1</p>  <p>Seat</p>	<p>Ex8</p>  <p>Spring washer</p>	<p>①</p>  <p>Tighten all the screws to 80% of maximum tightness</p>	<p>②</p>  <p>Tighten all the screws to 80% of maximum tightness</p>
<p>Bx2</p> 	<p>Fx8</p>  <p>M8x55mm</p> <p>Screw</p>		
<p>Cx2</p>  <p>Front leg</p>	<p>Hx1</p>  <p>M8</p> <p>Allen key</p>	<p>③</p>  <p>Close the zipper of bottom Non-Woven fabric.</p>	<p>④</p>  <p>Adjust the chair so that it is level, then fully tighten all the screws.</p>
<p>Dx8</p>  <p>Flat washer</p>			

WARNING:

DO NOT STAND ON THE PRODUCT, DO NOT USE THIS PRODUCT AS A STEP LADDER.
DO NOT USE THIS PRODUCT UNLESS ALL BOLTS, SCREWS AND KNOBS ARE FIRMLY SECURED.
PLEASE DO NOT USE KNIFE TO OPEN ANY PARTS OF THE BOX OR PRODUCT.