



INSTRUCTIONS FOR ASSEMBLING A BEACH TENT



Step 1 **Unpack and Lay Out the Tent**

Unfold the tent and spread it flat on the ground. **Ensure the corners are clearly visible** and untangled.

Step 2 **Connect the Tent Poles**

Locate the two folding tent poles. **These poles are linked** by elastic cords, making them easy to assemble. **Connect the segments** of each pole until both poles are fully extended.

Step 3 **Insert Poles into the Tent**

Find the loops on the tent where the poles will be inserted. These loops are **usually located diagonally across** the tent. **Insert one end of each pole** into the opening loop and slide it through until the pole reaches the opposite side. **Secure each pole end** into the grommets (small reinforced holes) at the base of the tent corners.

Step 4 **Raise the Tent**

With one person holding each pole, **gently lift the poles upright**, causing the tent to rise into shape.

Step 5 **Secure the Tent with Stakes**

Once the tent is raised, locate the fabric loops or straps at each corner of the tent. **Drive the stakes into the ground** through these loops at a 45-degree angle, ensuring the tent is stable and secure. **Make sure** all four corners are staked down evenly for proper tension.

Step 6 **Final Adjustments**

Check that the tent is fully upright and secure, and adjust the stakes or poles if necessary to ensure stability.