


Assembly Instruction



WARNING

Serious or fatal crushing injuries can occur from furniture tip-over. To help prevent tip-over.

- Place heaviest items in the lowest drawers.
- Do not set TVs or other heavy objects on the top of this product.
- Never allow children to climb or hang on drawer, door, or shelves.
- Never open more than one drawer at a time.


MAINTENANCE TIPS




Avoid liquid spraying or infiltrating on the product surface.



Never use chemical cleaning products. They will damage the finish.



To avoid dulling of finish, do not place furniture in direct sunlight.



Do not put plastic or rubber rings under appliances. Use cloth or felt protectors.



To clean, use a soft or slightly damp cloth, and wipe with a clean and dry cloth.



Sicherheitshinweise

Schwere oder tödliche Quetschverletzungen können durch Umkippen von Möbeln auftreten. Um ein Umkippen zu verhindern.

- Lege die schwersten Gegenstände in die untersten Schubladen.
- Legen Sie keine Überlastungsobjekte auf die Oberseite dieses Produkts.
- Lassen Sie Kinder niemals klettern oder an Schubladen, Tür oder Regale hängen.
- Öffnen Sie niemals mehr als eine Schublade gleichzeitig.


WARTUNGSTIPPE




Vermeiden Sie das Versprühen oder Eindringen von Flüssigkeiten auf die Produktoberfläche.



Verwenden Sie keine chemischen Reinigungsmittel. Sie können das Produkt beschädigen und müssen nach Abschluss der Reinigung nur mit einem leicht feuchten Tuch trocken abgewischt werden.









Um ein stumpfes Finish zu vermeiden, stellen Sie Furniture nicht in direktes Sonnenlicht.



Legen Sie keine Kunststoff- oder Gummiringe unter Geräte. Verwenden Sie ein Tuch aus Filzschutz.



Verwenden Sie ein weiches oder leicht feuchtes Tuch, wischen Sie es mit einem sauberen, trockenen Tuch ab.



DE


Wichtige Information

- Sorgfältig und aufmerksam lesen
- Diese Information aufbewahren


GB

Safety information

- Important information
- Please read closely and carefully
- Save this information




CAM LOCK




Nut should be in the centre of the cam lock when the two panels are joined.
Cam lock should be inserted before nut.

Wenn die beiden Platten verbunden sind, sollte die Mutter in der Mitte des Nockenschlosses sein.




























Die Nockenverriegelung sollte vor der Mutter eingeführt werden.




Parts List/Teileliste




PARTS LIST









1  600x300x12 x1 PC	7  598x66x12 x1 PC	13  238x116x12 x1 PC	19  572x80x12 x1 PC	25  272x60x12 x1 PC
2  720x283x12 x1 PC	8  286x66x12 x1 PC	14  523x116x12 x1 PC	20  536x296x15 x1 PC	26  600x300x12 x1 PC
3  720x283x12 x1 PC	9  286x66x12 x1 PC	15  224x60x12 x1 PC	21  536x296x15 x1 PC	27  904x282x1.2 x1 PC
4  572x282x12 x1 PC	10  570x66 x12 x1 PC	16  530x231x3 x1 PC	22  600x300x12 x1 PC	
5  572x258x12 x1 PC	11  596x174x15 x1 PC	17  579x183x3 x1 PC	23  272x60x12 x1 PC	
6  600x300x12 x1 PC	12  238x116x12 x1 PC	18  579x234x3 x2 PC	24  272x60x12 x1 PC	



Please prepare the following tools



When installing, please carefully confirm whether each screw corresponds to the manual, accessories with similar shapes can be distinguished by size


A x34 PC  6x35	B x34 PC  15x10	C x2 PC  10inches	D x4 PC  M3x12	E x10 PC  M3.5x12
F x14 PC/x1 PC  M5x40/#3	G x8 PC 	H x4 PC 	J x7 PC  6x40	K x12 PC   M3x14
L x14 PC  21mm	M x1 PC 	N x3 PC 	O x24 PC  M3.5x14	P x4 PC 

Step1

INSTALLATION STEPS



Press the plastic part in the indicated direction to separate drawer runner **C1** and **C2** before assembling.

REMARK: Please grip the **C1** part while sliding the **C2** part.





REMARK:

1. Please locate the holes from the back of part **C1**.





2. But install part **E** from the front of part **C1**.

Step2






1 2
3 4




J		x1
A		x5
F		x6


Step3



E		x2
N		x1
B		x5




Note: Distinguish fitting D from fitting E from fitting O.





C2		x2
D		x4

Step4

Installation method of three in one rod and buckle




Note: Distinguish fitting D from fitting E from fitting O.




P		x4
A		x8
E		x4
C1		x2

Step5




B		x4
---	---	----

Step6




Step7





B		x4
---	---	----

Step8






Step9





A		x4
B		x4

Step10




A		x2
F		x2

Step11




B		x2
G		x8

Step12




A		x8
---	---	----

Step13





B		x8
---	---	----

Step14







Step15





J		x6
---	--	----

Step16






A		x3
B		x3
F		x3

Step17





Step18




F		x3
---	---	----

Step19





A		x4
---	---	----

Step20





B		x4
---	---	----

Step21



K   x12



Step22



Step23

Hinge adjustment



To facilitate the adjustment, install the 01 screw first, and then install the 02 screw.



Hinge adjustment

a: To move doors up or down: loosen screws shown and move doors to suit.


Once doors are aligned, re-tighten Screws H



Hinge adjustment

b: To move doors in or out: loosen screw shown and move doors to suit.




Re-tighten screws




Hinge adjustment

c: To move doors left or right: loosen screw shown and move doors to suit.


Re-tighten screws



Step24




Note: Distinguish fitting D from fitting E from fitting O.




H		x4
O		x8

Step25




First install O1 , which allow for fine adjustment, then install O2 to secure the assembly.
Please note: The door panel can no longer be adjusted vertically after the O2 is installed.




Note: Distinguish fitting D from fitting E from fitting O.

N		x1
E		x2
O		x8

Step26



First install O1 , which allow for fine adjustment, then install O2 to secure the assembly.
Please note: The door panel can no longer be adjusted vertically after the O2 is installed.




N		x1
E		x2
0		x8

Note: Distinguish fitting D from fitting E from fitting O.

Step27


REMARK: Align the slide runners on the drawer with the unit and push it carefully inside until it stops.

★ If the drawer does not go in smoothly please take it out and repeat the step.





REMARK:

1. First, slide the slide and ball on both sides of the slide to the outside.
2. when installing the drawer, align both sides first, and then push both sides inward at the same time.




Step28




M		x1
---	---	----

Step29




Add L fittings to all exposed holes on the front of the product



L



x14



**Serious or fatal crushing injuries can occur from furniture tip-over.
To further reduce the risk of serious injury and death from tip-overs:**

Schwere oder tödliche Quetschverletzungen können durch Umkippen von Möbeln auftreten.

Um das Risiko schwerer Verletzungen und Todesfälle durch Umkippungen weiter zu reduzieren.

DE Sicherheitshinweise

- Wichtige Information
- Sorgfältig und aufmerksam lesen
- Diese Information aufbewahren



WICHTIG. Der Aufbau des Möbels muss zwingend nach Aufbauanleitung und durch eine fachkundige Person erfolgen. Sämtliche Elektro- und Sanitärinstallationen sind ausschließlich von autorisiertem Fachpersonal durchzuführen.

Um zu verhindern, dass ein Möbel umkippt, muss es fest an der Wand verankert werden. Eine fehlerhafte Montage bzw. fehlende Wandbefestigung kann zu Funktionsbeeinträchtigungen, Beschädigungen und/oder schweren Verletzungen führen.

Wegen der großen Vielfalt an Wänden und Wandmaterialien haben wir kein Befestigungsmaterial beigelegt. Bitte erkundigen Sie sich im Fachhandel nach geeignetem Befestigungsmaterial entsprechend Ihren baulichen Gegebenheiten. Sie sind für die Befestigung am Mauerwerk und den dort eingesetzten Materialien selbst verantwortlich.

Halten Sie die in der Montageanleitung angegebenen maximalen Gewichtsangaben ein. Beschlagbeutel, Beschlagteile und Verpackungsmaterial sind von Säuglingen und Kindern fernzuhalten, da verschluckbare Kleinteile enthalten sind und Erstickungsgefahr droht.

Werden Bedienungs-, Betriebs- oder Montageanweisungen nicht befolgt, Bauteile ausgewechselt, Änderungen an den Produkten vorgenommen oder Verbrauchsmaterialien verwendet, die nicht den Originalteilen entsprechen, so entfallen jegliche Haftungsansprüche und Gewährleistung. Wir haften nicht für Personen- oder Sachschäden, die auf eine unsachgemäße Montage bzw. nicht erfolgte Wandbefestigung zurückzuführen sind. Bei Überlastungen, die durch Menschen, spielende Kinder oder sonstige Einwirkungen entstehen, übernehmen wir als Hersteller keine Haftung.

GB Safety information

- Important information
- Please read closely and carefully
- Save this information



IMPORTANT. It is imperative that the furniture be installed according to instructions by someone properly qualified to complete the task. Installation of electrical or plumbing fixtures should only be performed by trained professionals.

The furniture must be anchored to the wall to prevent it from tipping over. Improper installation or failure to use wall fasteners can prevent the item from functioning properly and may cause damage and/or severe injury.

Wall fasteners are not included because of the large variety of walls and wall materials. Please ask a specialized dealer for wall fasteners appropriate to your specific needs. You are responsible for anchoring the items to the wall and for the materials used for that purpose.

Please observe the maximum load capacity as specified in the assembly instructions. Keep the bag containing the fittings, the fittings themselves and other packaging material out of reach of babies and children. The small parts can be swallowed and therefore pose a choking hazard.

Failure to follow handling, operation or assembly instructions, exchanging components, making changes to the product or using materials which differ from the original parts will result in voiding all liability claims and warranties. We accept no liability for personal or material damage due to improper installation or failure to properly anchor the item to the wall. We assume no liability as manufacturer for excessive loads placed on a unit by individuals, playing children or other causes.