WARNING:

THIS PORTABLE LAMP HAS A POLARIZED PLUG (ONE BLADE S WIDER THAN THE OTHER).AS A FEATURE TO REDUCE THE RISK OF ELECTRIC SHOCK THIS PLUG WILL FIT IN A POLARIZED OUTLET ONE WAY ONLY. IF IT DOES NOT FIT FULLY IN THE OUTLET REVERSE THE PLUG, IF IT STILL DOES NOT FIT, CONTACT A QUALIFIED ELECTRICIAN NEVER USE WITH AN EXTENSION CORD UNLESS THE PLUG CAN BE FULLY INSERTED.

- * Do not plug the power cord into the outlet until fully installed.
- * Do not exceed the recommended wattage.
- * Always allow bulbs to cool for 10 minutes before changing.

This fixture has been rated for up to three (3) E26 Socket 60-Watt maximum standard incandescent light bulbs (not included) of CFL of LED bulbs (not included).

To avoid the risk of fire, DO NOT EXCEED THE RECOMMENDED LAMP WATTAGE.

The lighting fixture is meant for indoor use.

Pls read the installation instructions carefully and follow the steps:

- 1. Install the arm into the pole (B4) and set it in a right position-socket face down straightly.
- 2. Connect the poles (B4, B3, B2, B1).
- 3. Connect the base (A) to the pole assembled and tight it well.
- 4. Attach the glass shade (C) to the socket.
- 5. Secure the glass shade with the socket ring.
- 6. Install the light bulbs.

