



3PC ROCKER WICKER PATIO SET

MAINTENANCE AND SAFETY INSTRUCTIONS

PRODUCT CARE INSTRUCTIONS

Thank you for your purchase! Your new patio set and accessories are designed for many years of enjoyment with proper care. Please adopt the following practices to ensure the longevity of your purchase.

General Cleaning

Regular cleaning should be done with a damp, non-colored, non-abrasive cloth soaked in clear water. Use mild soap as necessary. Avoid the use of abrasive cleaners and power washers. Clean spills immediately with a damp, non-colored, non-abrasive cloth and mild soap solution to avoid staining.

- Remove any cushions and clean them separately, according to the manufacturer's instructions, as proper care varies by fabric type.
- Regular dusting with a soft cloth, microfiber duster, or feather duster helps keep any type of wicker looking great.
- For heavier dust, use a small soft-bristled paintbrush; to remove dirt from those crevices where wicker meets the furniture frame, switch to an old toothbrush.
- Regularly clean wicker furniture with the brush attachment of your vacuum, being sure to set the suction to its lowest level to avoid causing damage.

WICKER CLEANING

An effective all-purpose cleaning solution for outdoor wicker furniture is 1/4 cup of liquid dish soap and two cups of warm water. Wipe the wicker with a soft cloth or sponge, then rinse away the soapy suds with a garden hose. For mold and mildew removal, add one cup of white vinegar to the solution.

Strategies for drying wicker include using a hairdryer, a fan, or the open air. If your wicker is synthetic, it can dry in the sun outside. If your wicker is natural, spot-drying with a hair dryer (on a cold air setting), or with a fan will work wonders. Do not let wet natural wicker stand for too long without drying, as it might grow mould or develop mildew. A regular clean keeps wicker furniture looking great and remaining strong; with these tips, you can handle the task with ease.

Using the product in a coastal environment places higher demand on the surface finish due to the effects of salty/corrosive air. More frequent cleaning (weekly or biweekly) is necessary to remove any buildup of salt residue. Quarterly application of a clear coat is necessary to maintain a strong surface finish in this type of environment.

For all items, avoid exposure, especially prolonged exposure to harsh environments including rain, snow, or other wet conditions, direct sunlight, extremely high or low temperatures, and salty or corrosive air. Products should be covered or brought indoors when not in use, especially when not in use for prolonged periods of time, or when otherwise exposed to harsh weather such as winter. Do not put hot items directly on furniture surface. Always use coasters, placemats, trivets, or hot pads. Do not clean with harsh cleaners or polish. Do not place near heating or cooling vents.

KEEP THESE INSTRUCTIONS