


Instruction Manual

Multifunctional Cabinet



Notes:

1. ASSEMBLY PREPARATION AND TIPS FOR ASSEMBLY

- 1). Remove all packaging materials, staples and packing straps from the carton.
- 2). Refer to Parts List and Hardware List, and ensure parts and hardware are correct before assembly.
Contact customer service for missing parts.
- 3). Place all wooden parts on a clean, flat and soft surface (e.g. carpet or rug) to prevent scratch and damage to parts.
- 4). Allow ample room for assembly and assemble the product near where the product will be placed.
- 5). During assembly, do not over-tighten any fittings as this may cause damage.
- 6). Always place the product on a flat, level surface.






















2. CARE AND MAINTENANCE

- 1). KEEP ALL HARDWARE PARTS OUT OF REACH OF CHILDREN.
- 2). Wipe clean with a soft, dry cloth; avoid the use of harsh chemicals or household cleaners as they may damage the exterior finish of the furniture.
- 3). Hardware may loosen over time. Periodically, check that all connections are tight; re-tighten as necessary.
















3. TIPS TO PROTECT & CARE FOR YOUR FURNITURE

- 1). Avoid placing your furniture in direct sunlight, as sunlight causes fading.
- 2). Use a protective pad when writing on the furniture surface.
- 3). Use cutting boards and trivets for food preparation in order to avoid damaging the top for the unit.


PART LIST

A 	B 	C 	D 	E 
Top Panel 1 PC	Left Panel 1 PC	Right Panel 1 PC	Partition Panel 1 PC	Bottom Panel 1 PC
F 	G 	H 	I 	J 
Foot Board 2 PCS	Back Panel 2 PCS	Large Drawer Front Panel 1 PC	Drawer Left Panel 2 PCS	Drawer Right Panel 2 PCS
K 	L 	M 	N 	O 
Large Drawer Back Panel 1 PC	Large Drawer Bottom Panel 1 PC	Fixed Shelf Panel 1 PC	Front Rail 1 PC	Back Rail 1 PC
P 	Q 	R 	S 	T 
Adjustable Shelf 1 PC	Small Drawer Front Panel 1 PC	Small Drawer Back Panel 1 PC	Small Drawer Bottom Panel 1 PC	Left Door 1 PC
U 				
Center / Right Door 2 PCS				


HARDWARE LIST

<div>#1</div>  <p>Ø3*12mm Screw</p> <p>3 PCS (Extra 1)</p>	<div>#2</div>  <p>Ø8*30mm Wood Dowel</p> <p>12PCS (Extra 4)</p>	<div>#3</div>  <p>Ø3*30mm Screw</p> <p>8PCS (Extra 2)</p>	<div>#4</div>  <p>Ø6*35mm Cam-bolt</p> <p>40PCS (Extra 4)</p>	<div>#5</div>  <p>Ø15*9mm Cam-lock</p> <p>40PCS(Extra 4)</p>
<div>#6</div>  <p>150*32*Ø12mm Handle</p> <p>5 PCS</p>	<div>#7</div>  <p>M4*22mm Round Head Bolt</p> <p>10 PCS (Extra 2)</p>	<div>#8</div>  <p>Back Bracket</p> <p>8 PCS (Extra 2)</p>	<div>#9</div>  <p>Ø3.5*14mm Screw</p> <p>12 PCS (Extra 2)</p>	<div>#10</div>  <p>70*17*13mm Double Door Magnet</p> <p>1 PC</p>
<div>#11</div>  <p>45*17*12mm Single Door Magnet</p> <p>1 PC</p>	<div>#12</div>  <p>Ø6*21*12mm Shelf Holder</p> <p>4 PCS (Extra 1)</p>	<div>#13</div>  <p>30*22*1mm Door Small Plate</p> <p>3 PCS</p>	<div>#14</div>  <p>Safety Strap Kit</p> <p>2 SET</p>	 <p>Phillips Screwdriver</p> <p>1 PC</p>


ASSEMBLY OVERVIEW



Instructions For Fastening CAM-BOLT and CAM-LOCK




CAM-BOLT




CAM-LOCK


Tools Required




INSERTING AND TIGHTENING CAM-BOLT



Place Cam-bolt on pre-drilled hole and screw in vertically




Shoulder is flushed (on the same level) with the panel.




Shoulder is above the panel.

Place Cam-bolt on the designated pre-drilled holes on the panel. Use a Phillips Screwdriver to screw-in Cam-bolt vertically until shoulder is flushed (on the same level) with panel.


INSERTING CAM-LOCK



Insert Cam-lock with arrow align to Cam-bolt head




CORRECT



WRONG



Align the arrow on the Cam-lock to the Cam-bolt head and insert the Cam-lock. Ensure Cam-lock is fully inserted.

TIGHTENING CAM-LOCK

















Use a Flat-head Screwdriver to turn Camlock clockwise so it locks onto the head of the Cam-bolt. Turn until it is snug (about 3/4ths of a turn) -- over-tightening could damage Cam-lock or/and Cam-bolt.


Step 1.





Step 2.





Note: Tighten it or it will cause wobble.




Step 3.





Step 4.





Step 5.




Note: Fully tighten #5 or it will cause wobble.




Step 6.





Step 7.





The magnet faces the smaller holes side.




Step 8.





Step 9.




Note: Fully tighten #5 or it will cause wobble.




Step 10.





Note: Fully tighten #5 or it will cause wobble.




Step 11.





Note: Fully tighten #5 or it will cause wobble.



Step 12.




Step 13.





Note:

1. The groove on B needs to be aligned with G.
2. Fully tighten #5 or it will cause wobble.




Step 14.




Note:


1. The groove on A needs to be aligned with G.
2. Fully tighten #5 or it will cause wobble.




Step 15.






Step 16.





Note: Adjustable for three heights.





Step 17.









Step 18.



Step 19.



#14 	A 	B  D8*3/4" 	C  D8*1-1/2" 	D 
Safety Strap Kit 2 SET	Wall Anchor 2 PCS	Short Screw 2 PCS	Long Screw 2 PCS	Safety Wall Strap 2 PCS



Warning:

Seller is responsible for the product-related issues occurred upon receipt, but will not be responsible for the personal injury, property damage or loss resulting from the incorrect assembly, improper use, inadequate maintenance or neglect of this product.