

Instruction Manuals

Caution : You must read this before you proceed

Crane




Parts List

Label	Picture	Description	QTY
A		Crane	1

Hardware


Label	Picture	Description	QTY
①		Stake	2
②		Hammer (not provided)	1

Step 1



Unpack and place all parts on a clean soft surface.

Step 2



Affix the Crane(A) to the ground by inserting the Stake(①) through the mounting position with Hammer(②).

Step 3



Your crane is ready for use.

Care & Maintenance

-  Do not put hot items directly on furniture surface.
 -  Do not clean furniture with harsh cleansers or polish.
 -  To obtain the longest lifespan of your outdoor products, minimizing exposure to direct sunlight is recommended.
 -  Children should not climb or jump on the furniture.
 -  Do not write on furniture without a padded barrier to protect the surface.
 -  To obtain the longest lifespan of your outdoor products, avoid extended and lengthy exposure to rain, snow, and direct sunshine. Whenever possible cover the product and /or place under patio or awnings.
 -  Not for commercial use. For residential use only .
 -  Stains may be removed with mild soap solution and damp cloth.
-
-  Dust and pick-up spills using a clean, non-colored, lint-free cloth .