



Assembly Instructions





WARNING

DEATH OR SERIOUS INJURY MAY OCCUR WHEN CHILDREN CLIMB ON AUDIO AND/OR VIDEO EQUIPMENT FURNITURE. A REMOTE CONTROL OR TOYS PLACED ON THE FURNISHING MAY ENCOURAGE A CHILD TO CLIMB ON THE FURNISHING AND AS A RESULT THE FURNISHING MAY TIP OVER ON TO THE CHILD.

MUERTE O LESIONES GRAVES PUEDEN OCURRIR CUANDO LOS NIÑOS SUBAN AL AUDIO Y / O MOBILIARIO EQUIPO DE VÍDEO. UN MANDO A DISTANCIA O LOS JUGUETES EXISTENTES EN EL MOBILIARIO PUEDE ANIMAR AL NIÑO A SUBIR A LOS MUEBLES Y COMO RESULTADO EL MOBILIARIO PUEDEN VOLCARSE A LA NIÑO(A).

MORT OU DES BLESSURES GRAVES PEUVENT SE PRODUIRE LORSQUE LES ENFANTS MONTER SUR L'AUDIO ET / OU DES MEUBLES DE L'ÉQUIPEMENT VIDÉO. UNE TÉLÉCOMMANDE OU LES JOUETS MIS SUR L'AMEUBLEMENT PEUVENT ENCOURAGER UN ENFANT À GRIMPER SUR LA FOURNITURE ET COMME RÉSULTAT L'AMEUBLEMENT PEUVENT BASCULER À L'ENFANT.



WARNING

RELOCATING AUDIO AND/OR VIDEO EQUIPMENT TO FURNITURE NOT SPECIFICALLY DESIGNED TO SUPPORT AUDIO AND/OR VIDEO EQUIPMENT MAY RESULT IN DEATH OR SERIOUS INJURY DUE TO THE FURNISHING COLLAPSING OR OVER TURNING ONTO A CHILD.

REUBICACIÓN DE AUDIO Y / O EQUIPO DE VÍDEO A LOS MUEBLES NO ESTÁN DISEÑADOS ESPECÍFICAMENTE PARA APOYAR EL EQUIPO DE AUDIO Y / O VÍDEO PUEDE CAUSAR LA MUERTE O LESIONES GRAVES DEBIDO A LA DECORACIÓN COLAPSE O MÁS DE INFLEXIÓN EN UN NIÑO.


DÉPLACEMENT AUDIO ET / OU VIDÉO À DES MEUBLES PAS SPÉCIFIQUEMENT DESTINÉ À SOUTENIR L'ÉQUIPEMENT AUDIO ET / OU VIDÉO PEUT ENTRAÎNER LA MORT OU DES BLESSURES GRAVES EN RAISON DE LA FOURNITURE DE S'EFFONDRE OU PLUS EN TOURNANT SUR UN ENFANT.

USE AND CARE

1. To clean, use a soft cloth slightly dampened with water.
2. Do not use abrasive cleaners or spray liquids.
3. Using solvents of any kind on your furniture may damage your furniture's finish.
4. Liquid spills should be removed immediately. Using a soft clean cloth, blot the spill gently. Avoid rubbing.
5. Stains or marks from crayons or ink markers will be difficult to remove.
6. Do not climb or step on the stand.
7. Periodically check that all fasteners are tightened.

-
1. Para limpiar, use un paño suave ligeramente humedecido con agua.
 2. No use limpiadores abrasivos o rociadores.
 3. El uso de disolventes de ningún tipo sobre sus muebles pueden dañar el acabado de sus muebles.
 4. Los derrames de líquidos deben ser retirados inmediatamente. Con un paño suave y limpio, seque el derrame suavemente. Evite frotar.
 5. Las manchas o marcas de crayones o marcadores de tinta serán difíciles de eliminar.
 6. No se suba o pisar el stand.
 7. Compruebe periódicamente que todos los sujetadores estén apretados.


-
1. Pour nettoyer, utilisez un chiffon doux légèrement humidifié avec de l'eau.
 2. Ne pas utiliser de nettoyeurs abrasifs ou de liquides en aérosol.
 3. L'utilisation de solvants d'aucune sorte sur vos meubles peut endommager le fini de votre mobilier.
 4. Les déversements de liquides doivent être retirés immédiatement. L'utilisation d'un chiffon propre et doux, éponger délicatement le déversement. Évitez de frotter.
 5. Taches ou les marques de crayons ou des marqueurs d'encre sera difficile à enlever.
 6. Ne pas monter ou marcher sur le stand.
 7. Vérifier périodiquement que toutes les fixations sont serrées.




MAXIMUM WEIGHT: 200 LBS (91 KG)
PESO MÁXIMO: 200 LIBRAS (91 KILOGRAMO)
POIDS MAXIMUM: 200 LIVRES (91 KILOGRAMME)

General Assembly Guidelines


- I. Ensure that all parts and hardware are available before beginning assembly.
- II. Follow each step carefully to ensure the proper assembly of this product.
- III. Two people are recommended for ease in the assembly of this product.
- IV. The three main types of hardware used to assemble this product are: wood dowels, screws and bolts.
- V. The provided glue is to secure wood dowels in place. When first inserting dowels, locate the appropriate hole for the dowel, place a small amount of glue in the hole and insert the dowel. Wipe away excess glue immediately.




In future assembly steps when dowels are necessary to attach assembly parts together, place a small amount of glue on the end of the dowel before attaching parts together. Wipe away excess glue immediately.




- VI. Power tools should not be used to assemble this product.




- VII. Cam bolt and Cam lock Assembly instruction.




Cam bolt
vertical installation.



Cam bolt is
adjustable




Cam lock
the arrow is towards
the Cam bolt




180°
Ensure locking

- VIII. It is recommended that two people install it.



COMPONENT PARTS






Hardware List

A		Ø8x30mm	Wooden dowel	40 pcs
B		Ø6x35mm	Cam bolt	52 pcs
C		Ø15x12mm	Cam lock	52 pcs
D			Sticker	12 pcs
E		Ø6x50mm	Screw	14 pcs
F		Ø4x30mm	Screw	32 pcs
G		4mm	Allen Key	1 pcs
I			Glue tube	1 pcs
J		Ø1/4"x12mm	Bolt	5 pcs
K		Ø1/4"x25mm	Bolt	7 pcs
M		Ø3.5x12mm	Screw	38 pcs
O			Wall anchor	1 pcs
P		Ø4*30mm	Screw	1 pcs
Q		Ø6mm	Washer	1 pcs
R			Philips head screwdriver	1 pcs

*The hardware quantities listed above are required for proper assembly.
Some extra hardware may also have been included.*



Step 1

B x 6	C x 6	R x 1
		
Ø6x35mm	Ø15x12mm	




Step 2

A x 2	B x 2	C x 2	R x 1
			
Ø8x30mm	Ø6x35mm	Ø15x12mm	




 Pay attention to the distance of the hole




Step 3

A x 2	E x 2	G x 1
		
Ø8x30mm	Ø6x50mm	4mm





The notch and slot are on the same side



Step 4



B x 8	K x 4	G x 1	R x 1
			
Ø6x35mm	Ø1/4**25mm	4mm	



There are only four holes on this side


Step 5

A x 6	C x 6	R x 1
		
Ø8x30mm	Ø15x12mm	



Step 6

A x 2	C x 2	R x 1
		
Ø8x30mm	Ø15x12mm	





Step 7

B x 6




R x 1



Step 8




A x 6



C x 6




R x 1




Step 9

A x 2	E x 2	G x 1
		
Ø8x30mm	Ø6x50mm	4mm



Step 10

B x 8	R x 1
	
Ø6x35mm	



Step 11

A x 2



Ø8x30mm

C x 4





Ø15x12mm

D x 2



R x 1



There are lead holes
on this side

Step 12

A x 2



Ø8x30mm

C x 4




Ø15x12mm

D x 2




R x 1



There are lead holes
on this side


Step 13

A x 6	E x 6	G x 1
		
Ø8x30mm	Ø6x50mm	4mm




Step 14

B x 14	R x 1
	
Ø6x35mm	




Step 15




A x 4	E x 4	G x 1
		
Ø8x30mm	Ø6x50mm	4mm




Step 16



A x 6	C x 14	R x 1
		
Ø8x30mm	Ø15x12mm	




Step 17




L x 4



R x 1



Step 18



G x 1




K x 3





Step 19

F x 24	R x 1
	
Ø4x30mm	






Step 20

M x 38	R x 1
	
Ø3.5x12mm	





Step 21





X2

Step 22




Step 23

C x 8	R x 1
 Ø15x12mm	




Step 24


D x 8





Step 25




Step 26



Step 27




Step 28




Step 29

G x 1	J x 1	N x 1
		
4mm	Ø1/4"x12mm	




Step 30

N x 1	O x 1	P x 1	Q x 1	R x 1
				
		Ø4x30mm	Ø6mm	




1	2
	

Step 31



Step 32



Final Assembly



WARNING



Children have died from furniture tip-over. To reduce the risk of furniture tip-over:

- Highly recommend installing tip-over restraint provided. (Step 24 and 25)
- NEVER put a TV on this product.
- NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- Place heaviest items in the lowest drawers.

