



Assembly Instructions

ITEM#: ZR200440 Large Iron "Merry Christmas" Archway with Santa's Elves and LED Lights

Please read instruction thoroughly before assembling the arch. Familiarize yourself with inventory of parts and the accompanying illustrations to assure safe and proper assembly.

Parts


A		B		C		D		E	
F		G		J		N		R	
					*2PCS				8MM *10PCS

Step 1



Attached(A) to (B).Using nuts with Spanner.
Don't tighten all bolts

Step 2




Attached (D) to (C),No need any nuts .

Step 3



Attached Pre-assembled bow(D,C) to pre-assembled arch part(A,B). Using Nuts with Spanner.
Pay attention:The battery box on the behind of arch.PLS TURN ON BEFORE NEXT STEP.
Don't tighten all nuts.


Step 4



Attached pre-assembledfull top part(A,B,C,D) to attached (F) & (G).Using Nuts with Spanner.

For easy to assemble, pls put the pillars on the floor.
Tighten all nuts and stand the whole arch.

Step 5



Attached (J) to (G) . No need nuts and bolts,just hanging on the hands.

Step 6



Attached pre-assembled assecories on Step 5 to (F) and (G) **No need any nuts and bolts ,just put the iron bar into the hole of balls.**

Finished



Your Christmas arch is ready to decorate your house.

IMPORTANT: Check all hardware for tightness before and during use

The assembly requires 3 people and will take approximately 30 minutes

Use and Care:

Safe for both indoor and outdoor use; year round.Clean with damp/dry cloth; use clear protective overspray (ex. Rustoleum) for added protection against potential fading and/or weatherization.

Zaer Ltd. International Warranty

Zaer Ltd. products have a 30 day warranty that begins once product is delivered.
Questions/Comments: Call 215-766-2010 or email sales@zaerltd.com.

Visit www.ZaerLTD.com to shop our entire selection of wholesale home & garden decor!