

INSTRUCTION


FOOTBALL GOAL: CD-FG011

MANUAL


Read carefully and keep for future reference. Assembly should be done by adults only.

part list


N°	Description	SPECIFICATION	Qty
1	Pole "L"	72,5cm	4
2	Pole "L"	54,2cm	2
3	Straight pole	87cm	2
4	Straight pole	88cm	2
5	Straight pole	80,5cm	2
6	Straight pole	38,2cm	2
7	Support Pole	78cm	2
8	Support Pole	78,5cm	2
9	Net		1
10	Net Fasteners		18
11	Screws	4cmx0,6	4
12	Spring button	Pre-assembled	16
13	hook	16cm	4





STEP 1



STEP 2



STEP 3&4



STEP 1: Assemble the frame by sliding the handles of the net(N9).

STEP 2: Assemble the SUPPOET(N7&N8) onto the frame using screws N11.

STEP 3: Turn the net fasteners(N10) to adjust the thread tension.

STEP 4: Fix the goal with the ground hooks(N13)

