


TOOLS REQUIRED









2 - People Recommended

ASSEMBLY RATING



The Assembly Rating is a

5-point system showing the level of effort needed to assemble a specific product.

VERSION # 22-01-05



Are you missing anything?	Check out our Quick Tips!
Double-check all parts, hardware and accessories listed are all acccounted for.	We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then!
Should we send any replacements? Are there any irregularities or flaws in the parts? We can send replacements!	Prep Time! Please review the assembly instructions and all diagrams prior to assembling.

PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.





Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.





Suitable Location

Assembling near the area of the intended location is highly recommended.





Sufficient Space

Make sure you have enough space to move around during the assembly.





Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent to prevent scratches and damages.





Flat Surface

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.

ASSEMBLY AND CARE ADVICE




FAILURE TO FOLLOW THE GUIDELINES BELOW MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.



Position each part correctly and insert screws or bolts into their respective holes.



Use the appropriate hand tools or power tools for assembly. Select steps, such as tightening screws and/or bolts, may require hand tools to avoid causing damage during assembly.



Turn clockwise to tighten and only tighten when step is completed or when instructed to do so.



Save the instructions and store any supplied tools for later maintenance.




After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.


IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.

LARGE COFFEE TABLE



- Please keep instructions for future reference.
- Check the quantity and irregularity of parts and hardware before you start.





Box Panel


Box Panel

HARDWARE (#A)x 8pcs #C)x 16pcs (#B)x 12pcs Bolt 1/4" * 1" Bolt 1/4" * 9mm Screw 4mm * 9mm (#D) x 4pcs (#E)x 16pcs (#F)x 13pcs *ammmmm* Screw 9# * 2" Dowel Plug (#G) x 1pc #H)x 1pc

Allen Wrench

Glue








2

Part # x2pcs
Part * x2pcs
Pardware * x16pcs

Align panel (#8) to frame (#1), then secure using screws (#C).









SMALL COFFEE TABLES




- · Please keep instructions for future reference.
- Check the quantity and irregularity of parts and hardware before you start.








Side Frame





Bottom Board

(#2)x 2pcs



Side Frame


#6)x 4pcs



521mm x 102mm

Panel

(#3)x 4pcs



Cross Frame


x 4pcs




266mm x 102mm


Panel

HARDWARE










(#4)x 2pcs

Flip Board











Bolt 1/4" * 1"






(#E)x 4pcs









Caster



Caster with Brake



Allen Wrench



Wrench

1

Part #1 x2pcs


Part #2 x2pcs

Part #3 x4pcs


Part #6 x4pcs
Part #7 x4pcs


Hardware#C x32pcs


Align panels (#6) to side frames (#1,2), then secure by using screws (#C).



**Be care of the directions when assembly, and keep the panels (#6, #7) align center.











Align hinges of flip board (#4) to side frame (#2), secure using screw (#B).





ASSEMBLY COMPLETED



Please ensure the furniture rests on an even and flat surface. If the product wobbles or feels loose, double-check all bolts and/or screws are properly tightened and secured.

✓ Keep this handy!

Please retain this instruction manual and any order-related information for future reference.

✓ Lift, don't drag!

To avoid damage to product please always LIFT the product when transporting of adjusting the placement.