



GB WARNING! READ THE FOLLOWING BEFORE STARTING INSTALLATION


Only use your product when fully assembled as described in the instruction Book. If the product is damaged in any way stop using immediately and consult the store where you purchased your product for guidance.

We continually strive to improve our products, specifications may change without prior notice.


- Incorrect assembly can result in severe personal injury and property damage.
- Do not tilt chair or lean over the sides – always ensure all casters are firmly placed on a level surface.
- Children should not play with the chair.
- Do not lean over the arms. This could cause the product to become unbalanced and result injury.
- Always use the chair on a flat, stable surface to prevent injury.
- Do not stand on chair.
- If the damaged product is irreparable please dispose of the product. Using a damaged product may lead to personal injury.
- This appliance is intended for indoor household use.
- Only trained personnel can replace or repair seat height adjustment components with energy accumulators.
- Keep this instruction manual for future reference.

Check and make sure you get the components on the list, contact us for any missing


A Back Cushion x1




B Seat Cushion x1




C Seat Plate x1



D Right Armrest x1




E Left Armrest x1




F Gas Lift x1



G Gas Lift Cover x1



H Base x1



I Caster x5



J Screw(1/4"x3/4") x4




K Screw(1/4"x1") x8



L Plastic Caps x8




M Allen Wrench(5mm)




Installation step


1




2



3




4



5



6





110 kg

