




ASSEMBLY INSTRUCTIONS

MODEL NO.:JAVA-5


①





1



x4










2







②

Parts List

| | | | | | | | |
|---|---|---|---|---|--|---|---|
| 1 |  | 2 |  | 3 |  | 4 |  |
| 5 |  | 6 |  | 7 |  | | |

Hardware List

| | | | |
|---|--|---|---|
| AX56 | BX32 | CX16 | DX1 |
|  |  |  |  |

