

ASSEMBLY INSTRUCTIONS

Bench



***THIS ASSEMBLY MANUAL CONTAINS IMPORTANT SAFETY INFORMATION.
PLEASE READ AND KEEP FOR FUTURE REFERENCE.***

Important Safety Information

- *Please read all instructions carefully before assembling this furniture.*
- *For your safety, assembly by two or more adults is strongly recommended.*
- *Use only vendor-supplied hardware to assemble this item. Using unauthorized hardware could jeopardize the structural integrity of the item.*
- *Hardware may loosen overtime. Periodically check that all connections are tight.*




Before Assembly

- *Power tools are highly recommended for assembly.*
- *Remove all parts and hardware from the box. Place all items on a carpeted or scratch-free work surface, as this will avoid damaging parts during assembly.*
- *The shipping box provides an ideal work surface.*
- *To avoid accidentally discarding small parts or hardware, do not dispose of any packaging or contents of the shipping carton until assembly is complete.*
- *Use the parts and hardware lists below to identify and separate each of the pieces included.*
- **Note:** *Do not fully tighten all bolts until all parts are in place. Failure to follow these instructions may cause the bolts to misalign during assembly.*

Care and Cleaning

- *Routine cleaning of the furniture can be completed with only warm water and soap.*
- *You can use the sanding sponge for cleaning.*

Components

A		2
B		1
C		2
D		4

Hardware

E

M6*75mm Bolt

Qty: 8




It is recommended to use power tools for installation

Tools Needed for Assembly




Allen key

Step 1




Step 2

E M6*75 mm Bolt
Qty: 2




Step 3

E M6*75 mm Bolt	
Qty: 2 	



Step 3

E M6*75mm Bolt	
Qty: 4 	



Return & Refund Policy

We are committed to safeguarding your every shopping experience, ensuring that your shopping experience is happy, safe, and environmentally friendly. To prevent bad effects due to unclear terms, we have the following refund and return policy. Please read the following terms carefully.

1. Returns without product quality problems

——30 days return period

Free return

The items must be unopened, unused, and in the same condition and original packaging as when you received them. Send the pictures and order number of the items to support@efurden.com

2. Products arrive damaged or incomplete

——7 days return period

Free return

Send the pictures/videos and order number of the defective items to support@efurden.com. Tell us what you want: Replacement or refund

3. Products with quality problems

——12 months warranty period since you receive the items

Free return

Send the pictures/videos and order number of the defective items to support@efurden.com, we will provide you full refund or part replacement.

Any overdue requests will not be accepted.

For exchanges (Same product) with quality problems, you will not be charged any additional product, shipping, or service fees. For refunds, we will offer a percentage based on the condition of products and orders, please contact us at support@efurden.com to discuss refund issue.

Once refund is approved, we will process the refund within the promised time (Approximately 3-5 business days), and the refund will be only returned to your original payment cards.

We reserve the right to refuse refunds or exchanges that do not comply with our return policy.

Delivery

Due to the large size of the product, our orders may be packaged and shipped separately, and they may not arrive at the same time. You can contact us by email to learn about the arrival status of other packages.