

# ASSEMBLY INSTRUCTION

ITEM NO: TDL212140DS


1) Fix the shade (3) knob onto the lamp holder of lamp body (2).

\*Please note that there is a knob dimmer switch on the plug wire that can adjust the brightness of the light bulb.

**CAUTION** – Refer to the wattage caution label located near the lamp holder for recommended maximum wattage - Do not exceed recommended wattage.

**WARNING** – Do not attempt to replace the bulb while the lamp is plugged into a wall receptacle.

**IMPORTANT SAFETY INSTRUCTIONS** This portable lamp has a polarized plug(one blade is wider than the other)as a safety feature to reduce the risk of electric shock.This plug will fit in a polarized outlet only one way.if the plug does not fit fully in the outlet,reverse the plug.If it still does not fit,contact a qualified electrician.Never use with an extensioncord unless plug can be fully inserted.Do not alter the plug.



E12, Type B, 15W (NOT INCLUDED)