



Children's Scooter User Manual












1.Press and hold the spring buckles on both sides, align the handlebar tube with the vehicle body, and clip it in downwards




2.Adjust the handlebar and open the handlebar lock buckle




3.The handlebars can be adjusted to 5 gears




4.Hold down the buckle and lift the handlebar upwards




5.Adjust the handlebar to the appropriate gear and fasten the handlebar lock buckle



6.Rear brake, one step and stop



7.Swing left and right to turn



8.Installation completed