
ASSEMBLY INSTRUCTION

OUTDOOR SECTIONAL SOFA SET



Notice:

1.80% Tighten before fixing all screws, Allen wrench is recommended instead of an electric drill.

2. Place the item on a flat ground to adjust and make sure it remains stable.

3. Tighten up all screws with tools gradually.

4. If the screws are not aligned with holes during asembly, please loosen all the other screws to 50% and continue the assembly process.

5. If the item is not stable, please loosen all the screws,adjust it on a flat ground and tighten up all screws again.

6. **Note**: If one or some screws are fully tightened during assembly, chances are the others will not be aligned with holes. In addition, all the holes are designed to be relatively larger to provide more space for the adjustment of the screws.

Assembly Instruction

Caution: You must read these Assembly Instructions before you proceed

Care & Maintenance

⊘  ● Not for commercial use. For residential use only.

⊘  ● Do not put hot items directly on furniture surface.

⊘  ● Do not clean furniture with harsh cleansers or polish.

✓  ● To obtain the longest lifespan of your outdoor products, minimizing exposure to direct sunlight is recommended.

⊘  ● Prolonged exposure to rain may cause rusting which can stain floors.

⊘  ● Children should not climb or jump on the furniture.

⊘  ● Do not write on furniture without a padded barrier to protect the surface.


✓  ● To obtain the longest lifespan of your outdoor products, avoid extended and lengthy exposure to rain, snow, and direct sunshine. Whenever possible cover the product and /or place under patio or awnings.


⊘  ● Stains may be removed with mild soap solution and damp cloth.


✓  ● Keep away from sources of ignition.


✓  ● Dust and pick-up spills using a clean, non-colored, lint- free cloth.

OUTDOOR SECTIONAL SOFA SET










CAUTION : This Outdoor Sectional Sofa Set is NOT a TOY.

- Keep your child / children at bay in the process of assembly.
- For turning the outdoor sectional sofa set and to prevent damage to the outdoor sectional sofa set two adults may be needed to execute this action.


Part List :

A1 1 pc




Corner chair-leg 1

A2 1 pc




Corner chair-leg 2

A3 1 pc




Corner chair-leg 3

A4 1 pc




Corner chair-leg 4

A5 1 pc




Left chair - Left Leg

A6 1 pc




Left chair - Right Leg

A7 1 pc




Right chair - Right Leg

A8 1 pc




Right chair - Left Leg

A9 2 pcs




Side table- Legs panel

B 1 pc




Corner chair - Seat panel

C 2 pcs




Long Seat panel

D1 1 pc




Corner chair - Left backrest panel

D2 1 pc



Corner chair - Right backrest panel

E1 1 pc




Corner chair - top rail 1

E2 1 pc




Corner chair - top rail 2

E3 1 pc




Corner chair - top rail 3

F 2 pcs




Long backrest panel

G 2 pcs



Long top rail


H 2 pcs



Side table top


Part List :

I	2 pcs




Support Rail

J	2 pcs



Support Legs

K	2 pcs



Flower pot

L	4 pcs




Table legs

M	1 pc






Table top

N1	1 pc




Short pillow

N2	1 pc




Corner pillow

O	4 pcs




Long pillow

P	1 pc



Corner Seat cushion

Q	2 pcs



Long Seat cushion

Hardware list:

1	36 pcs + Extra 3pcs	2	42 pcs + Extra 3pcs	3	1 pc + Extra 1pc	4	87 pcs + Extra 3pcs	5	8 pcs + Extra 1pc	6	2 pcs



Bolt M6x30



Bolt M6x15




Bolt M6x50



Washer M6x15x1




Nut M6




Allen Wrench

7	1 pc



wrench

8	4 pcs




Shape collection

CARTON CONTENT:


(Box 1)

A9 2 pcs



Side table-Legs panel

B 1 pc



Corner chair-Seat panel

M 1 pc






Table top

O 4 pcs



Long pillow


P 1 pc



Corner Seat cushion


(Box 2)

A1 1 pc




Corner chair - leg 1

A2 1 pc



Corner chair - leg 2

A3 1 pc




Corner chair - leg 3

A4 1 pc




Corner chair - leg 4

A5 1 pc




Left chair-Left Leg

A6 1 pc




Left chair-Right Leg

A7 1 pc




Right chair-Right Leg

A8 1 pc



Right chair-Left Leg

K 2 pcs




Flower pot

L 4 pcs




Table legs

N1 1 pc




Short pillow

N2 1 pc



Corner pillow




Hardware

CARTON CONTENT:


(Box 3)

C | **1 pc**




Long Seat panel

D1 | **1 pc**



Corner chair-Left backrest panel

D2 | **1 pc**




Corner chair-Right backrest panel

E2 | **1 pc**




Corner chair - top rail 2

I | **2 pcs**




Support Rail

J | **2 pcs**




Support Legs

H | **2 pcs**



Side table top


Q | **1 pc**



Long Seat cushion


(Box 4)

C | **1 pc**




Long Seat panel

E1 | **1 pc**




Corner chair - top rail 1

E3 | **1 pc**




Corner chair - top rail 3

F | **2 pcs**




Long backrest panel

G | **2 pcs**




Long top rail


Q | **1 pc**




Long Seat cushion




1






① x2	④ x2

2




① x2	③ x1	④ x3

3




② x6	④ x6

4




② x2	④ x2

5




① x8	④ x8


6



②x10	④x10

7







Adjust high for balance	Adjust low to balance


Adjust pre-installed levelers height of balance

8





9






1






① x2	② x1	④ x3

2




① x2	② x1	④ x3

3




① x4	④ x4

4




②x4	④x4

5




②x2	④x2

6





① x4	④ x4

7



② x4	④ x4







Adjust high for balance	Adjust low to balance


Adjust pre-installed levelers height of balance

9




10







1

①x2	②x1	④x3






2




① x2	② x1	④ x3

3




① x4	④ x4

4




②x4	④x4

5




②x2	④x2

6





① x4	④ x4

7



② x4	④ x4






Adjust high for balance


Adjust low to balance

Adjust pre-installed levelers height of balance


9




10





11







1








⑤ x8	④ x8





Adjust high for balance	Adjust low to balance

Adjust pre-installed levelers height of balance

