

Assembly Instructions

Caution : You must read these Assembly Instructions before you proceed

Care & Maintenance



- Not for commercial use. For residential use only.



- Do not put hot items directly on furniture surface.



- Do not clean furniture with harsh cleansers or polish.



- To obtain the longest lifespan of your outdoor products, minimizing exposure to direct sunlight is recommended.



- Children should not climb or jump on the furniture.



- Do not write on furniture without a padded barrier to protect the surface.



- To obtain the longest lifespan of your outdoor products, avoid extended and lengthy exposure to rain, snow, and direct sunshine. Whenever possible cover the product and /or place under patio or awnings.




- Stains may be removed with mild soap solution and damp cloth.



- Dust and pick-up spills using a clean, non-colored, lint-free cloth.









Please look into the Seat Panel for hardware packs.

DINING CHAIR



CAUTION: This Dining chair is NOT a TOY.
Keep your child / children at bay during the assembly process.
Whenever lifting or moving the **Dining chair** and to prevent any damage to it, two adults may be needed to execute these actions.

Part List


Label	Picture	Description	QTY
A		Left Back Leg Panel	1
B		Right Back Leg Panel	1
C		Support Backrest Panel	2
D		Right Leg Panel	1
E		Left Leg Panel	1
F		Vertical Support Seat Panel	1
G		Seat Panel	1
H		Horizontal Support Seat Panel	2
L		Seat Cushion	1
M		Back Cushion	1

Hardware

Label	Picture	Description	QTY
①		Screw (M6x20mm)	5
②		Screw (M6x55 mm)	3
③		Screw (M6x60 mm)	3
④		Bolt (M6x30mm)	9
⑤		Sleeve Nut (M6x15mm)	3
⑥		Allen Wrench	2

Assembly Preparation

Before Beginning Assembly:



- Read instructions, cover to cover-



- Have 2 adults on hand for assembly-



- Do not assemble on flooring or carpet-




- Assemble on a clean non-marring surface (packing foam)-



- Save all packaging until finished-


Assembly Steps

Overview




This Dining Chair has multiple parts and may require up to **30 minutes** to assemble. To give you an overview of the **Dining chair parts**, the above picture is provided to help you put the various parts into perspective. Please read through the instructions below to familiarise yourself with the parts and steps before assembly.

Step 1



Unpack and place all parts on a clean, non-marring surface.

Step 2




Place the Left Back Leg Panel (A), The Right Back leg Panel (B) and the Support Backrest Panel (C) lie as shown in the picture above onto a clean, soft surface to avoid any scratches or damage to the product.


Attach the Left Back Leg Panel (A) and The Right Back leg Panel (B) to the Support Backrest Panel (C) by using the Screw ((1)) and the Allen Wrench ((6)) as shown above.

DO NOT fully tighten the Screws at this time.

Step 3



3.1



3.2


Place the Left Leg Panel (E), The Vertical Support Seat Panel (F) and the Seat Panel (G) lie as shown in the picture above onto a clean, soft surface to avoid any scratches or damage to the product.

3.1 Attach the Left Leg Panel (E) to the Seat Panel (G) by using the Bolt (4) and the Allen Wrench (6) as shown above.

3.2 Attach the Vertical Support Seat Panel (F) to the Left Leg Panel (E) by using the Bolt (4) and the Allen Wrench (6) as shown above.

DO NOT fully tighten the Bolts at this time.

Step 4




Place the assembled parts in step 3 and the Right Leg Panel (D) lie as shown in the picture above onto a clean, soft surface to avoid any scratches or damage to the product.

Attach the Right Leg Panel (D) to the assembled parts in step 3 by using the Bolt (4) and the Allen Wrench (6) as shown above.


DO NOT fully tighten the Bolts at this time.

Step 5




Place the assembled parts in step 4 and the Horizontal Support Seat Panel (H) lie as shown in the picture above. Attach the Vertical Support Seat Panel (F) in step 3 to the Horizontal Support Seat Panel (H) by using Screws (③) and the Allen Wrench (⑥) as shown above.
DO NOT fully tighten the Screws at this time.

Step 6




Place the Assembled parts in step 2 and the assembled parts in step 5 as shown in the picture above onto a clean, soft surface to avoid any scratches or damage to the product. Attach the Assembled parts in step 2 and the assembled parts in step 5 by using the Bolt (④), the Sleeve Nut (⑤) and the Allen Wrench (⑥) as shown above.
DO NOT fully tighten the Bolts at this time.

Step 7



Place the assembled parts from step 6 in an upright position as shown in the illustration. Attach the Assembled parts in step 2 and the assembled parts in step 6 by using the Screw (②) and the Allen Wrench (⑥) as shown above.
DO NOT fully tighten the Screws at this time.


Step 8



Turn the Dining Chair right side up.
Inspect the Dining Chair and make sure all parts are adequately connected.
In a sequential manner, tighten all Screws and Bolts at all joints.
With assistance from your adult partner, adjust the Levelers to the desired height to avoid wobbles.


CAUTION: When tightening these screws and bolts, tighten sequentially.
DO NOT tighten any screw or bolt fully and then move towards the next one. This could cause the frame to warp.
WARNING!! IF THE DINING CHAIR IS NOT STABLE , IT COULD LEAD TO DAMAGING THE PRODUCT.

Step 9



Place Seat Cushion (L) onto the Dining Chair.
Then affix the Velcro straps around the Dining Chair as shown above.
Fully tighten the Velcro straps to stabilize the chair.

Step 10



Place Back Cushion (M) onto the Chair.
Then affix the Velcro straps around the Chair as shown above.
Your **Dining chair** is ready to be used.
This **Dining chair** can only be used on a flat, level surface.

Questions & Answers about Proposition 65

• What is Proposition 65?

Proposition 65 requires businesses to provide warnings to Californians about significant exposures to chemicals that cause cancer, birth defects or other reproductive harm. These chemicals can be in the products that Californians purchase, in their homes or workplaces, or that are released into the environment. By requiring that this information be provided, Proposition 65 enables Californians to make informed decisions about their exposures to these chemicals.

Proposition 65 also prohibits California businesses from knowingly discharging significant amounts of listed chemicals into sources of drinking water.

Proposition 65 requires California to publish a list of chemicals known to cause cancer, birth defects or other reproductive harm. This list, which must be updated at least once a year, has grown to include approximately 900 chemicals since it was first published in 1987.

• What types of chemicals are on the Proposition 65 list?

The list contains a wide range of naturally occurring and synthetic chemicals that include additives or ingredients in pesticides, common household products, food, drugs, dyes, or solvents. Listed chemicals may also be used in manufacturing and construction, or they may be byproducts of chemical processes, such as motor vehicle exhaust.

• What does a warning mean?

If a warning is placed on a product label or posted or distributed at a workplace, a business, or in rental housing, the business issuing the warning is aware or believes that it is exposing individuals to one or more listed chemicals.

By law, a warning must be given for listed chemicals unless the exposure is low enough to pose no significant risk of cancer or is significantly below levels observed to cause birth defects or other reproductive harm.

• Where can I get more information on Proposition 65?

If you have specific questions on the administration or implementation of Proposition 65, you can contact OEHHA's Proposition 65 program at P65.Questions@oehha.ca.gov, or by phone at (916) 445-6900.