



| ITEM | PART NO | DESCRIPTION | ITEM | PART NO | DESCRIPTION |
|------|-----------|----------------------------|------|-----------|---------------------|
| 1 | BX-S004 | SPRAY VALVE | 12 | BXF-B12 | ADD-ON FAUCET |
| 2 | BX-S080 | GASKET | 13 | BX-S018-1 | SCREW |
| 3 | BX-S081 | SPRAY VALVE HOLD DOWN RING | 14 | BX-S018-2 | INDEX BUTTON |
| 4 | BX-S082 | HANDLE ASSEMBLY | 15 | BX-S018-3 | HANDLE |
| 5 | BX-S083 | WASHER | 16 | BX-S015 | VALVE |
| 6 | BX-S009 | STAINLESS STEEL HOSE | 17 | BX-S047 | VALVE BODY |
| 7 | BX-S030 | SPRING | 18 | BXF-69 | COUPLING NUT WASHER |
| 8 | BX-S084 | SPINDLE BODY | 19 | BX-S036 | ECCENTRIC |
| 9 | BX-S031 | WALL BRACKET | | | |
| 10 | BX-S032-1 | FINGER HOOK | | | |
| 11 | BX-S032 | LONG RISER | | | |