


ASSEMBLY INSTRUCTION SS14146BK/SS14147BK

————— Porch Swing Cover —————




ATTENTION


If there is any damage, please send us clear photos of the damaged parts as attachments. We will check and offer you the best solution soon. If there are any missing items or other issues, please feel free to contact our customer service team for assistance

Assembly Instruction

STEP1



STEP2



STEP3

