

NOTES:

- The item is only intended to be used indoors. The product must be assembled and used in accordance with the provisions of the manual.
- It is recommended that assembly is undertaken by about 2 adults. Please read assembly instructions before assembly and strictly adhere to each step outlined. Estimated assembly time is 30 minutes.


WARNING:


 WARNIND FOR YOUNG CHILDREN - This product contains small components, please ensure that they are kept away from small children while assembling.


PARTS LIST


A			В			\mathbf{C}			D		
2PCS			1PC			1PC			1PC		
E			F			G			\mathbf{H}		
4PCS			6PCS			2PCS			2PCS		
I			J			K			L		
2PCS			2PCS			2PCS			4PCS 1PC		
aa	bb	сс	dd	ee	ff	gg	hh	ii	jj	kk	11
1/4*85	1/4*45	1/4*40	1/4*35	1/4*18	1/4*15		1/4	(0)	1/4	1/4	
4PCS	1/4*45 4PCS	6PCS	4PCS	1/4*18 8PCS	1/4*15 4PCS	4PCS	4PCS	8PCS	1/4 2PCS	2PCS	1PC


NOTE: PLEASE DO NOT TIGHTEN THE BOLTS UNTIL ALL FIXED











Warranty Information:

We warranty this product to be free from defects in materials. This warranty covers one year from the date of original purchase.