


ZFK036



INSTRUCTION MANUAL




ASSEMBLY INSTRUCTIONS

Carefully unpack all the components and verify that all the necessary parts are included as listed in the packaging.

Identify each component and refer to the provided assembly diagram or step-by-step instructions. Assemble the furniture in the order specified to ensure proper alignment and fit. Use the provided tools or recommended tools for assembly. Do not use excessive force when tightening screws or bolts.

If any difficulties arise during assembly, consult the troubleshooting section or contact our customer support.

Tools Required












Phillips Head Screwdriver



Flat Head Screwdriver

















Hardware Parts List


NO.	PICTURE	QTY	NO.	PICTURE	QTY	NO.	PICTURE	QTY
①	 Ø15X9.5mm Cam Lock	29+3	⑥	 Ø4X20mm Screw	6+1	⑪	 Ø5X16mm Shelf Support	4+2
②	 Ø6.5X35mm Cam Bolt	29+3	⑦	 Ø4X35mm Screw	8+1	⑫	 31X31X26mm Handle	2
③	 Ø6X30mm Wooden Dowel	18+2	⑧	 66X25X7mm Hinge	4	⑬	 M4X18mm Screw	2+1
④	 Ø3X14mm Screw	14+2	⑨	 96X21X14mm Magnetic Bump	1	⑭	 Back Panel Buckle	12+2
⑤	 Ø3X12mm Screw	18+2	⑩	 26X21X1mm Iron Sheet	2	⑮	 Ø21mm Screw Hole Sticker	29+3

Hardware Parts List

NO.	PICTURE	QTY	NO.	PICTURE	QTY	NO.	PICTURE	QTY
⑩		2						
	Anti-Tipping Device							


Board Parts List

NO.	PICTURE	QTY	NO.	PICTURE	QTY	NO.	PICTURE	QTY
①		1	⑦		2	⑭		1
	Front Panel			Side Panel Left and Right Support Bar			Bottom Panel	
②		1	⑧		1	⑮		1
	Panel Support Bar			Right Rear Leg			Front Crossbar for the Bottom Panel	
③		1	⑨		1	⑯		1
	Door Magnetic Lock			Right Front Leg			Left Door Panel	
④		2	⑩		1	⑰		1
	Side Panel			Back Panel			Right Door Panel	
⑤		1	⑪		1			
	Left Rear Leg			Middle Shelf				
⑥		1	⑫		1			
	Left Front Leg			Bottom Panel Rear Support Bar				










Cam Lock Fastening System

Insert the cam bolt into the designated hole and secure it in place by inserting the cam lock.













ASSEMBLY INSTRUCTIONS

STEP1





ASSEMBLY INSTRUCTIONS

STEP2








Insert the cam bolt into the hole first, then insert the cam lock and lock it.




Proper orientation of CAM LOCK

ASSEMBLY INSTRUCTIONS

STEP3











Insert the cam bolt into the hole first, then insert the cam lock and lock it.





Proper orientation of CAM LOCK

 ASSEMBLY INSTRUCTIONS








Insert the cam bolt into the hole first, then insert the cam lock and lock it.




Proper orientation of CAM LOCK

ASSEMBLY INSTRUCTIONS

STEP5











Insert the cam bolt into the hole first, then insert the cam lock and lock it.





Proper orientation of CAM LOCK

ASSEMBLY INSTRUCTIONS

STEP 6









Insert the cam bolt into the hole first, then insert the cam lock and lock it.



Proper orientation of CAM LOCK






ASSEMBLY INSTRUCTIONS

STEP 7




ASSEMBLY INSTRUCTIONS

STEP8




Insert the cam bolt into the hole first, then insert the cam lock and lock it.









Proper orientation of CAM LOCK

STEP9




ASSEMBLY INSTRUCTIONS

STEP10








Insert the cam bolt into the hole first, then insert the cam lock and lock it.



Proper orientation of CAM LOCK






ASSEMBLY INSTRUCTIONS

STEP11






ASSEMBLY INSTRUCTIONS

STEP12










☰ ASSEMBLY INSTRUCTIONS

STEP13




ASSEMBLY INSTRUCTIONS

STEP14



ASSEMBLY INSTRUCTIONS


STEP 15




We have provided a set of tipping restraint hardware for this unit, and it is essential to install this hardware to prevent accidents or injuries that may occur if the unit tips over. When correctly installed, this restraint can offer protection against unexpected tipping caused by minor vibrations, impacts, or climbing. We highly recommend attaching this hardware to a wall stud and securing it to your unit for safety.

NOTE: The provided tipping restraint hardware is designed for use with wooden stud wall construction and should be affixed to a wall stud. If your wall construction differs, you may require alternative anchor hardware. Please consult your local hardware store for guidance. It's crucial to be aware that young children are at risk of serious injury from furniture tipping over, so you must install the provided tipping restraint hardware with the unit to prevent accidents or damage. These restraints serve as a deterrent and are not a substitute for responsible adult supervision. It's important to note that the tipping restraints are not designed for earthquake safety. If you wish to enhance security for earthquake situations, separate earthquake restraints must be acquired and installed.


Install The Anti-Tipping Device




1. Mark the wall for reference.




2. Drill two Ø6 holes in the wall.




3. Insert two anchors into the holes.



4. Secure the device to the wall using the provided long screws.



5. Position the cabinet near the wall, aligning the two bases. Attach a nylon tie to ensure a snug fit.





MAINTENANCE AND CARE

Clean with a chicken feather duster or a soft cloth, avoiding water. Use a damp, soft cloth if necessary, preferably made of pure cotton knit. Use a soft wool board brush for dust in recesses or embossed details.

If the edges of the furniture lift or separate, place a thin cloth on top and gently iron with a heated iron to re-adhere.

When placing the furniture, avoid contact with hard or sharp objects to prevent scratching.

Avoid dragging or placing heavy objects on furniture to prevent scratching and deformation.

Keep furniture away from dampness, high temperatures, and direct sunlight. Use curtains during summer to shield furniture from sun exposure.

Refrain from contact with corrosive liquids such as acids or alkalis.

Do not use harsh chemicals or abrasive cleaning agents.

Periodically apply furniture wax to the surface to prevent fading and sun damage.

Regularly inspect furniture joints and promptly reinforce any loose components.



WARRANTY INFORMATION

Warranty Coverage: Our warranty provides protection against manufacturing defects in materials and workmanship for a specified period from the date of purchase, as outlined in the accompanying warranty documentation.

Exclusions: The warranty does not cover damages resulting from misuse, negligence, accidents, normal wear and tear, unauthorized repairs or modifications, improper assembly, or failure to adhere to the care and maintenance guidelines provided.

Warranty Claim Process

To initiate a return on Amazon, please follow these steps:

- ① Log into your Amazon account and go to the "Your Orders" section.
- ② Locate the order containing the item you wish to return.
- ③ Contact our customer service for assistance in obtaining a prepaid return label.
- ④ Once you receive the return label, securely affix it to the package.
- ⑤ You can then choose to drop off the package at a designated carrier location or arrange for a pickup.
- ⑥ After we receive and inspect the returned product, we will initiate the refund process.
- ⑦ The refund will be credited back to the original payment method used during the purchase.
- ⑧ Typically, refunds are processed within 3-5 business days.



Contact Information

If you have any questions, concerns, or need assistance,
please reach out to our customer support team using the contact information

provided below:

Customer Support Email

support@sunvivi.com
