

Wooden shoescabinet





















Maintenance :

1. Avoid exposure to direct sunlight and heat sources.
2. Keep the cabinet door closed when not in use.
3. Use mild furniture cleaners to clean the cabinet.
4. Open the cabinet door gently at the bottom of drawers.

Parts list

	1	1pc	630*294*15mm	12	6pcs 544 *135*12mm
	2	1pc	598*294*15mm	13	3pcs 535 *149*12mm
	3	1pc	598*294*15mm	14	3pcs 594 *198*12mm
	4	1pc	1346*294*15mm	15	3pcs 267 *232*12mm
	5	1pc	1346*294*15mm	16	3pcs 267 *232*12mm
	6	1pc	595 *90*15mm	17	1pc 249 *76*12mm
	7	3pcs	595 *323*15mm	18	1pc 249 *76*12mm
	8	1pc	600 *40*15mm	19	1pc 550 *76* 12mm
	9	2pcs	599 *76*12mm	20	3pcs 606 *288*4mm
	10	1pc	599 *76*12mm	21	1pc 560 *247*4mm
	11	1pc	599 *76*12mm		

Hardware fitting list


 	 	 	  
22 50pcs	23 50pcs	24 24pcs	25 24pcs	26 6pcs	27 6pcs	28 29
3*25mm 	3*16mm 	3*12mm 	4*12mm 	  		
30 4pcs	31 8pcs	32 32pcs	33 12pcs	34 2pcs	35 2pcs	36 2pcs	37 6pcs	38 8pcs

GLS11327


Assistance must be required for assembly of this product

Please read the instructions carefully before assembling the cabinet.
Two adults are required for assembly of this product on a clean, flat surface without a rough surface that could scratch the panels.


(Drawer Assembly Instruction)




(Drawer Runner)




(tipping shoe rack)






GLS11327


(Side panels and panels)



(Bottom brace)




(Backplane)




GLS11327


(Back plate buckle)



(fixed to the wall)



(drawer)



GLS11327