




Display Cabinet





ASSEMBLED BY 2 ADULTS




IMPORTANT INFORMATION!

please read the entire manual before starting to assemble and/or using this product. follow the manual thoroughly and keep it for further reference.






AVOID SCRATCHES!

In order to avoid scratching this furniture should be assembled on a soft layer-could be a rug.



IMPROVE EFFICIENCY !

Try to find a partner to install with you, which can speed up the installation efficiency and shorten the time.



ANTI-TOPPLE WARNING !


Overturned furniture can cause serious or fatal crush injuries. To prevent tipping over, be sure to use the wall attachment, if not included with this product. Please purchase the wall attachment that fit your wall. If unsure, seek professional advice. Please read and follow each step of the instructions carefully.

IMPORTANT !




It is important that any product which is assembled using any kind of screw is re-tightened 2 weeks after assembly, and once every 3 months - in order to assure stability throughout the lifespan of the product.

For regular maintenance and cleaning of the product, for the frame, please use a rag dipped in neutral detergent to fully wipe it, and then dry it with a clean rag. For glass materials, wipe with a rag dampened with water glass cleaner, and then dry with a dry rag.

Do not use an electric screwdriver, and do not use too much force when installing, because the board is easy to break.



Please prepare the following tools



When installing, please carefully confirm whether each screw corresponds to the manual, accessories with similar shapes can be distinguished by size

A x 76 +4



Ø6 x 35mm

B x 76 +4



Ø15 x 10mm

C x 34 +3



Ø6 x 30mm

D x 52 +4



Ø4 x 35mm

E x 120 +4



Ø3 x 10mm

F x 2



Ø4 x 12mm

G x 16 +2




Ø3 x 12mm

H x 16 +2



J x 2




K x 2




CL x 10



CR x 10




DL x 10



DR x 10





⚠ WARNING








Children have died from furniture tipover. To reduce the risk of furniture tipover:

- ALWAYS install Anti-tip device provided.
- NEVER put a TV on this product.
- NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heaviest items in the lowest drawers.

*This is a permanent label.
Do not remove!*

1

A x 10
Ø6 x 35mm








2

E x 24
Ø3 x 10mm






CL x 4

CR x 4



3

A x 10
Ø6 x 35mm








4

E x 24
Ø3 x 10mm

CL x 4





CR x 4



5

B x 5
Ø15 x 10mm





C x 5
Ø6 x 30mm



6

B x 5
Ø15 x 10mm





C x 5
Ø6 x 30mm




7


B x 5
Ø15 x 10mm





C x 5
Ø6 x 30mm






8




B x 5

 Ø15 x 10mm

C x 5

 Ø6 x 30mm




9



E x 12  Ø3 x 10mm	CL x 2 	CR x 2 
--	---	---





X2




10

C x 4  Ø6 x 30mm	D x 4  Ø4 x 35mm
---	---



11



12

A x 10







Ø6 x 35mm

F x 2



Ø4 x 12mm

J x 2



13

B x 10











Ø15 x 10mm

C x 10



Ø6 x 30mm





14

G x 16



Ø3 x 12mm

H x16



15

D x 2








Ø4 x 35mm


K x 2




Ø6 x 30mm




1.




2.



3.










4.



16

A x 16
Ø6 x 35mm





17

D x 16



Ø4 x 35mm






18

B x 8



Ø15 x 10mm







19

B x 8



Ø15 x 10mm




20

E x 12






Ø3 x 10mm

DL x 2




DR x 2




21






E x 12



DL x 2



DR x 2






22


A x 20



Ø6 x 35mm








X2





23

A x 10
Ø6 x 35mm




24

D x 30
Ø4 x 35mm







X6




25

B x 20
Ø15 x 10mm








X2



26

B x 10
Ø15 x 10mm




27

E x 24






Ø3 x 10mm



DL x4



DR x 4



X2




28

E x 12



Ø3 x 10mm

DL x2



DR x 2

