





WARNING

"IMPORTANT, RETAIN FOR FUTURE REFERENCE: READ CAREFULLY"













































1. Must use ground nails, ropes, and expansions screws for whichever ground you install on for stability to avoid devastating injuries for people inside or nearby and property damage caused by a collapsing gazebo.
2. Do not use this gazebo in high winds, heavy snow, or inclement weather. It is not designed to withstand strong gusts of wind, heavy snow accumulation, or other inclement weather. Must take precautions when the wind speed exceeds 25Mph, and clear snow when it accumulates more than 2 inches.
3. Before use, thoroughly inspect the gazebo to make sure all bolts, nuts, and buckles have been completely tightened and securely fastened.
4. Warranty does not cover damages, losses, or injuries resulting from improper installation, misuse, not using stability accessories mentioned above, non snow cleaning, failure to take precautionary measures, etc.






































1. Two or more people are required for assembly.
2. A ladder and electric drill may be necessary.
3. Do not erect the structure in heavy winds or inclement weather.
4. Do not leave up this unit for extended periods of time, as it is not a permanent structure or designed to withstand sustained wind or rain. It is a temporary, portable shelter that shields you from sunlight and rain. The screens also block flying insects.
5. Do not use candles, matches, or any open flames near the tent.
6. To better align the screws for practical situations, do not fully tighten screws initially.
7. Professional installation is highly recommended.

Item no.	Reference Image	Qty.
A		X2
A1		X2
B		X2
B1		X2
B2		X2
B3		X2
Ea		X4
Eb		X4
E		X4
F1		X4
F2		X4
G1		X2
G2		X2

Item no.	Reference Image	Qty.
G3		X2
G4		X2
G5		X2
G6		X2
G7		X2
G8		X2
H		X4
H1		X4
J		X4
J1		X4
L		X1
M		X1
N		X12
N1		X4
Z		X88
Z1		X16


Item no.	Reference Image	Qty.	Item no.	Reference Image	
T		X4	1	 M6x16	X72
T1		X4	2	 M5x12	X8
V1		X2	3	 M6x25	X8
V2		X2	4	 ST 4.8x12	X8
U		X120	5	 M6x10	X8
W		X4	6	 M6x42	X20
W1		X4	7	 M6x47	X40
Y		X144	8	 M8x45	X32
P		X8	9	 M8	X64
C		X4	10	 M8x165	X16
C1		X4	11		X80
D		X4	12	 M8x55	X16
W2		X4	13	 ST6x40	X108

Item no.	Reference Image	Qty.	Item no.	Reference Image	Qty.
14		X16	Q1		X2
15		X2	Q2		X2
16		X12	Q3		X2
17		X12	Q4		X2
18		X4	Q5		X2
19		X32	Q6		X2
20		X8	Q7		X2
21		X1	Q8		X2
22		X1	R1		X2
23		X1	R2		X2
24		X2	R3		X2
S		X2	R4		X2
Sa		X2	R5		X2


Item no.	Reference Image	Qty.
R6		X2
R7		X2
R8		X2
R9		X2
R10		X2
S1		X2
S2		X2
S3		X2
S4		X2

1


X4




Ⓐ 2pcs




Ⓐ1 2pcs




Ⓓ 4pcs





Ⓙ 4pcs




⓵1 4pcs



19 32pcs



STEP1



STEP2

2

X2



Ⓑ 2pcs




Ⓑ1 2pcs



Ⓑ2 2pcs



Ⓑ3 2pcs






Ⓟ 8pcs



⑧ 32pcs



⑨ 32pcs




3

X2




⑨ 8pcs



⑩ 8pcs




⑪ 16pcs



4




⑨ 8pcs




⑩ 8pcs



⑪ 16pcs



⑫ 8pcs



5

X4



Ⓜ4pcs



Ⓜ14pcs



⑨16pcs




⑪32pcs



⑫16pcs



⑬16pcs



6



⑥4pcs



⑥a4pcs



⑥b4pcs



①1pc




①8pcs






①612pcs



①712pcs





①84pcs




7
X4



①4pcs



8



W2 4pcs




1 4pcs




2 8pcs



4 8pcs




9



Ⓜ 1pc







⑮ 2pcs







10

X2




11

X2



12




13



G1 2pcs




G2 2pcs





N 4pcs



1 6pcs




1




E


1




14




Ⓕ4pcs



Ⓖ4pcs







⒰4pcs






⒰4pcs








Ⓛ24pcs




15




16




17




18



19




① 128pcs




⑬ 80pcs








③ 8pcs






⑥ 4pcs



⑦ 36pcs



20



21



Ⓒ4pcs




Ⓒ14pcs




Ⓔ16pcs





Ⓔ16pcs




22




Ⓣ4pcs






23




T1 4pcs



14 16pcs





Installation Completed