



ASSEMBLY INSTRUCTIONS

COASTER FINE FURNITURE



Fine Furniture for every stage of life

903073

Accent Chair

ITEM: **903073**

ASSEMBLY INSTRUCTIONS




ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME

15 MINUTES

PARTS IDENTIFICATION

A **CHAIR**



1PC

B **LEG**




4PCS

ITEM: **903073**


ASSEMBLY INSTRUCTIONS




STEP 1





STEP 2




STEP 3



STEP 4 COMPLETE



ITEM:903073



Note: Dimension tolerance $\pm 5\%$