ASSEMBLY INSTRUCTION

Ax1	Ex1		
Bx1	Fx4	L L L L L L L L L L L L L L L L L L L	
Cx1	Gx1	F H O	
Dx1	Hx4	В	
PLEASE REMOVE BLACK GAP FROM GAS LIFT		A	