

Metal Plate Installtion Steps



Remove the nut



Slide the nut to the bottom section of the mop pole



Insert the mop pole into the mop head



Slide nut down towards mop head, and tighten

